



Bobcat®

GRADER

Including
Scarifier


Operation & Maintenance Manual

S/N 802700872 & Above
S/N 231511101 & Above

PDF



DOWNLOAD



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.



CONTENTS

FOREWORD	iii
SAFETY	vii
OPERATING INSTRUCTIONS	1
GRADER MAINTENANCE	19
SPECIFICATIONS	27

FOREWORD

SAFETY

**OPERATING
INSTRUCTIONS**

**GRADER
MAINTENANCE**

SPECIFICATIONS

**CALIFORNIA
PROPOSITION 65 WARNING**
Diesel engine exhaust and some of its
constituents are known to the State of California
to cause cancer, birth defects and other
reproductive harm.

REFERENCE INFORMATION

Write the correct information for YOUR Grader in the spaces below. Always use these numbers when referring to your Grader.

Grader Serial Number _____

NOTES: _____

YOUR LOADER DEALER:

ADDRESS:

PHONE:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
J. Huysmanslaan 59
B-1651 LOT
Belgium



Bobcat Company is ISO 9001 certified

ISO 9001 is a set of international standards that control the processes and procedures which we use to design, develop, manufacture, distribute, and service Bobcat products.

British Standards Institute (**BSI**) is the Certified Registrar Bobcat Company chose to assess the Company's compliance with the ISO 9001 set of standards. The BSI registration certifies that the two Bobcat Company manufacturing plants and the Bobcat Company corporate offices (Gwinner, Bismarck & West Fargo) in North Dakota are in compliance with ISO 9001. Only certified assessors, like BSI, can grant registrations. Since registration requires this *third-party auditing*, it is irrefutable evidence of conformance. Continued certification is subject to periodic audits.

ISO 9001 means that as a company we say what we do and do what we say . In other words, we have established procedures and policies, and we provide evidence that the procedures and policies are followed.

FOREWORD

FOREWORD

This Operation & Maintenance Manual was written to give the owner/operator instructions on the safe operation and maintenance of the Grader. **READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR GRADER.** If you have any questions, see your Bobcat loader dealer.

SERIAL NUMBER LOCATION	v..
ATTACHMENT DELIVERY REPORT	v. .
GRADER IDENTIFICATION & MACHINE SIGNS (DECALS)	vi



Thank you very much
for your reading.
Please click here
to get more information.