

Root Grapple 82 Inch



Bobcat®

VersaHANDLER®


Operation & Maintenance Manual

S/N A2MW00101 & Above

PDF



DOWNLOAD



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.



Printed in U.S.A.

CONTENTS

FOREWORD	III
SAFETY INSTRUCTIONS	IX
OPERATING INSTRUCTIONS	OI-1
PREVENTIVE MAINTENANCE	PM-1
SPECIFICATIONS	SPEC-1

REFERENCE INFORMATION

Write the correct information for YOUR Root Grapple in the spaces below. Always use these numbers when referring to your Bobcat Root Grapple.

Bobcat Root Grapple
Serial Number

NOTES

YOUR BOBCAT® DEALER:

ADDRESS:

PHONE:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
J. Huysmanslaan 59
B-1651 LOT
Belgium

FOREWORD

**SAFETY
INSTRUCTIONS**

**OPERATING
INSTRUCTIONS**

**PREVENTIVE
MAINTENANCE**

SPECIFICATIONS



Bobcat®

This manual gives the owner/operator necessary operating, and preventive maintenance instructions for the Bobcat Root Grapple.

Read this manual completely and know the Bobcat Root Grapple before operating and servicing it. All references to left or right on the attachment are given in relation to the operator's left or right hand while in the operator's seat.

For further information, see your Bobcat dealer. Parts Manuals, Service Manuals and extra Operation & Maintenance Manuals are also available.

BOBCAT COMPANY IS ISO 9001:2000 CERTIFIED	V
PARTS IDENTIFICATION	VIII
DELIVERY REPORT	VII
SERIAL NUMBER LOCATIONS	VII



Thank you very much
for your reading.
Please click here
to get more information.