

Workshop Service Manual

Challenger

Articulated Tractor

**MT945E
MT955E
MT965E
MT975E**



North America
4205 River Green Parkway, Duluth GA 30096 USA
Challenger is a registered trademark of Caterpillar
Inc. and is used under license by AGCO.
© AGCO 2019

June 2019
79036231G
NA
English

Challenger

**CALIFORNIA
Proposition 65 Warning**

WARNING: Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, or other reproductive harm.

WARNING: Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. Wash hands after handling.

Articulated Tractor

1	General	1-1
1.1	Safety information	1-3
1.1.1	A word to the technician	1-3
1.1.2	Service manual	1-4
1.1.3	Safety symbol	1-4
1.1.4	Safety messages	1-4
1.1.5	Information messages	1-4
1.1.6	Safety signs	1-5
1.1.7	Important safety information	1-5
1.1.8	General hazard information	1-6
1.1.9	Pressurized air	1-7
1.1.10	Asbestos information	1-7
1.1.11	Electrical storm injury prevention	1-7
1.1.12	Mount and dismount the machine	1-7
1.1.13	Before you start the engine	1-8
1.1.14	Start the engine	1-8
1.1.15	Before operation	1-8
1.1.16	Procedures for operation	1-8
1.1.17	Park the machine	1-9
1.1.18	Operator station	1-9
1.1.19	Cut and crush prevention	1-10
1.1.20	Rollover protective structure	1-10
1.1.21	Burn prevention	1-10
1.1.22	Coolant	1-11
1.1.23	Oils	1-11
1.1.24	High pressure lines	1-11
1.1.25	Fluid penetration	1-12
1.1.26	Batteries	1-12
1.1.27	Exhaust fumes	1-13
1.1.28	Noise prevention	1-14
1.1.29	Fire and explosion prevention	1-14
1.1.30	Fire extinguisher	1-15
1.1.31	Public road transportation	1-15
1.2	Serial number definition	1-16
1.3	Proper disposal of waste	1-17
1.4	Lubricant viscosities and refill capacities	1-18
1.4.1	Lubricant viscosities for ambient temperatures	1-18
1.4.2	Lubricant viscosities	1-18
1.4.3	Fill capacities	1-18
1.5	Service intervals	1-19
1.5.1	Maintenance chart	1-19
1.5.2	Maintenance schedule	1-20
1.6	Engine specifications - MT900E	1-22
1.7	Torque specifications	1-24
1.7.1	Constant torque hose clamps	1-24
1.7.2	Inch fasteners	1-24
1.7.3	Metric fasteners	1-27
1.8	Machine specifications	1-29
1.8.1	Machine specifications MT900E	1-29
1.8.2	Shipping weights MT900E	1-31



Thank you very much
for your reading.
Please click here
to get more information.