



WE/WS 2300 SERIES MAINTENANCE MANUAL



PDF



DOWNLOAD



Order number: 812567-006
Revision: B • Printed in Germany

This master manual is subject to continual updates.
It is intended solely for companies authorized by CROWN.
The content of this manual, including copies, may not be transmitted to third parties.

CROWN Gabelstapler GmbH & Co. KG
– European Headquarters –
Moosacher Str. 52
80809 Munich
Germany

Tel: +49 (0)89 93 00 2 - 0
Fax: +49 (0)89 93 00 2 - 133





TABLE OF CONTENTS



Notes:



TABLE OF CONTENTS

TABLE OF CONTENTS

SAFETY	PAGE	SERIAL NO. CUT	REV.
Symbols Used	3		
Safety Symbols	3		
General Symbols	3		
Fork direction	3		
General Safety Instructions	4		
Maintenance and Repair Instructions	4		
Maintenance and Repairs	4		
Before Parking the Truck	4		
Before Working on the Truck	4		
Before Starting the Truck	4		
Warning and Instruction Decals on the Truck	4		
INTRODUCTION	PAGE	SERIAL NO. CUT	REV.
General	9		
Operator Manual	9		
Service Training	9		
Ordering Spare Parts	9		
Using the Manual	9		
Models	10		
LUBRICATION & ADJUSTMENT	PAGE	SERIAL NO. CUT	REV.
Component Access	13		
Drive Unit Cover	13		
Control Handle	13		
Control Handle Knuckle	13		
Mast	13		
Platform and Side Restraints ⁽²⁾	13		
Component Access	15		
Drive Unit Cover	15		
Control Handle	15		
Control Handle Knuckle	15		
Mast	15		
Platform and side restraints ⁽²⁾	15		
Lifting the Truck	17		
Lifting with a Crane	17		
Lifting with a Forklift Truck	18		
Towing the Truck	19		
Jacking up the Truck	20		
.....	20		
Service	21		
Recommended Lubricants	21		
Cold Store Trucks	21		
Taking the Truck out of Service	21		
Returning the Truck to Service	21		
Recommended Lubricants and Consumables	22		
Inspection and Maintenance Schedule	24		
Daily or Every 8 Service Hours	25		
Safety Reverse Switch Test	27		
Test and Maintenance Interval Chart	28		



Thank you very much
for your reading.
Please click here
to get more information.