

F440M and F440R Round Baler Diagnostics (Worldwide Edition)



DIAGNOSIS AND TESTS MANUAL

Round Balers models F440M, F440R

TM300819 01 DEC 15 (ENGLISH)

For complete service information also see:

F440M and F440R Round Baler Repair (Worldwide Edition)

TM300919



John Deere Agriculture
Printed by Belgreen



Table of contents

FOREWORD

Section 210 - GENERAL INFORMATION

- Group 05 - Safety Information
- Group 15 - General References

Section 211A - DIAGNOSTIC TROUBLE CODES FOR BALETRAK BALER

- Group 05 - Description for BaleTrak Baler
- Group BTC - Diagnostic Trouble Code List for BaleTrak Baler

Section 211B - DIAGNOSTIC TROUBLE CODES FOR VIRTUAL TERMINAL BALER

- Group 05 - Description for Virtual Terminal Baler
- Group RBC - Diagnostic Trouble Code List for Virtual Terminal Baler

Section 212 - TROUBLESHOOTING

- Group 10 - Bale Density/Gate Control - Troubleshooting

Section 240A - ELECTRICAL SYSTEM - BALETRAK BALER

- Group 05 - General Information for BaleTrak Baler
- Group 30 - Schematic - BaleTrak Baler
- Group 50 - Diagnostic Tests - BaleTrak Baler
- Group 50B - Diagnostic Modes - Channels 0XX and 3XX
- Group 50C - Machine Setup - Channels 2XX

Section 240B - ELECTRICAL SYSTEM - VIRTUAL TERMINAL BALER

- Group 05 - General Information for Virtual Terminal Baler
- Group 30 - Schematic - Virtual Terminal Baler
- Group 50 - Diagnostic Tests - Virtual Terminal Baler
- Group 50B - Diagnostic Modes - Virtual Terminal Baler
- Group 50C - Machine Setup - Virtual Terminal Baler

Section 249 - CONNECTOR AND COMPONENT INFORMATION

- Group 35 - Electrical Component Location
- Group 40A - Component Information - Control Units
- Group 40E - Component Information - Lights
- Group 40H - Component Information - Signalling Device
- Group 40K - Component Information - Relays
- Group 40M - Component Information - Actuators
- Group 40N - Component Information - Terminating Resistors
- Group 40R - Component Information - Potentiometers
- Group 40S - Component Information - Sensors and Switches
- Group 40W - Component Information - Wiring Harnesses
- Group 40X1 - Component Information - Connectors (XB101 to XB199)
- Group 40X3 - Component Information - Connectors (XB301 to XB399)
- Group 40X4 - Component Information - Connectors (XB401 to XB499)
- Group 40X5 - Component Information - Connectors (XB501 to XB599)
- Group 40X7 - Component Information - Connectors (XB701 to XB799)
- Group 40X8 - Component Information - Connectors (XB801 to XB899)
- Group 40X9 - Component Information - Splices (XB901 to XB999)
- Group 40XO - Component Information - Connectors (Others)
- Group 40Y - Component Information - Solenoids

Section 260A - AIR BRAKE SYSTEM OPERATION AND TESTS

- Group 05 - Safety
- Group 20 - Air Brake System - Description
- Group 25 - Air Brake System - Tests

Section 260B - HYDRAULIC BRAKE SYSTEM OPERATION AND TESTS

- Group 20 - Hydraulic Brake System - Description
- Group 25 - Hydraulic Brake System - Tests

Section 270 - HYDRAULIC SYSTEM

Group 05 - Hydraulic Systems - Safety and General Information

Group 20 - Hydraulic Systems - Theory of Operation

Group 30A - Hydraulic Schematic: Bale Density / Gate Control

Group 30B - Hydraulic Schematic: Rotary Feeder

Group 50 - Hydraulic Systems - Diagnostic Tests and Adjustments

Section 279 - HYDRAULIC SYSTEM - COMPONENT INFORMATION

Group 35A - Hydraulic Connections: F440M Baler

Group 35B - Hydraulic Connections: F440R Baler

Group 40 - Hydraulic Component Information

Section 399 - SPECIAL TOOLS

Group 05 - Special Tools (Dealer-Fabricated)

Group 10 - Special Tools (Available as Spare Parts)

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

**CAUTION:**

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections (up to Section 200) tell how to repair the components. Operation and tests sections (from Section 200) help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.



Thank you very much
for your reading.
Please click here
to get more information.