





Bobcat®

Operation & Maintenance Manual Front Mount Snowblower

(Blower FMSB49) S/N AUPG00101 & Above
(Blower FMSB62) S/N AU4T00101 & Above
(Blower FMSB62) S/N B3WS00101 & Above



CONTENTS

CONTENTS	1
FOREWORD	3
SAFETY AND TRAINING RESOURCES	9
OPERATING INSTRUCTIONS	19
PREVENTIVE MAINTENANCE	47
MACHINE SIGN TRANSLATIONS	73
SPECIFICATIONS	83
WARRANTY	87
ALPHABETICAL INDEX	91

REFERENCE INFORMATION

Write the correct information for YOUR Bobcat attachment in the spaces below. Always use these numbers when referring to your Bobcat attachment.

Attachment Serial Number _____

NOTES:

YOUR BOBCAT DEALER:

ADDRESS:

PHONE:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
Drève Richelle 167
B-1410 WATERLOO
Belgium



Bobcat®

FOREWORD

This Operation & Maintenance Manual was written to give the owner / operator instructions on the safe operation and maintenance of the Bobcat attachment. READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR BOBCAT ATTACHMENT. If you have any questions, see your Bobcat dealer.

BOBCAT COMPANY IS ISO 9001 CERTIFIED	5
SERIAL NUMBER LOCATION	6
Attachment Serial Number	6
DELIVERY REPORT	6
ATTACHMENT IDENTIFICATION	7
FEATURES AND ACCESSORIES	8
Standard Items	8



Thank you very much
for your reading.
Please click here
to get more information.