




Bobcat®

Operation & Maintenance Manual Three-Point Soil Conditioner

(3SC60H) S/N AH8P00101 & Above
(3SC60M) S/N AJKZ00101 & Above
(3SC72H) S/N AH8L00101 & Above
(3SC72M) S/N AJL400101 & Above



CONTENTS

CONTENTS	1
FOREWORD	3
SAFETY & TRAINING RESOURCES	9
OPERATING INSTRUCTIONS	19
PREVENTIVE MAINTENANCE	73
MACHINE SIGN TRANSLATIONS	87
SPECIFICATIONS	93
WARRANTY	101
ALPHABETICAL INDEX	105

REFERENCE INFORMATION

Write the correct information for the Bobcat implement in the spaces below. Always use these numbers when referring to your Bobcat implement.

Implement Serial Number _____

NOTES:

YOUR BOBCAT DEALER:

ADDRESS:

PHONE:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128
UNITED STATES OF AMERICA

Doosan Benelux SA
Drève Richelle 167
B-1410 Waterloo
BELGIUM



Bobcat®

FOREWORD

This Operation & Maintenance Manual was written to give the owner/operator instructions on the safe operation and maintenance of the Bobcat implement. **READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR BOBCAT IMPLEMENT.** If you have any questions, see your Bobcat dealer.

BOBCAT COMPANY IS ISO 9001 CERTIFIED	5
SERIAL NUMBER LOCATION	6
Implement Serial Number	6
DELIVERY REPORT	6
IMPLEMENT IDENTIFICATION	7
FEATURES AND ACCESSORIES	8
Standard Items	8



Thank you very much
for your reading.
Please click here
to get more information.