

# 1999-2002 Yamaha YZF-R6L, YZF-R6CL Motorcycle Service Repair Workshop Manual





# YAMAHA

[How to use this manual](#)

[Identifying Symbols](#)










[Go to Index](#)

# YZF-R6L

# YZF-R6CL


## Service Manual

# INDEX

GENERAL INFORMATION	
	GEN INFO <b>1</b>
SPECIFICATIONS	
	SPEC <b>2</b>
PERIODIC CHECKS AND ADJUSTMENTS	
	CHK ADJ <b>3</b>
ENGINE OVERHAUL	
	ENG <b>4</b>
COOLING SYSTEM	
	COOL <b>5</b>
CARBURETORS	
	CARB <b>6</b>
CHASSIS	
	CHAS <b>7</b>
ELECTRICAL	
	ELEC <b>8</b>
TROUBLESHOOTING	
	TRBL SHTG <b>9</b>

KA00954

## FRONT BRAKE MASTER CYLINDER AND BRAKE FLUID RESERVOIR



Order	Job/Part	Q'ty	Remarks
	<b>Removing the front brake master cylinder and brake fluid reservoir</b>		Remove the parts in the order listed.
	Brake fluid		Drain.
1	Brake fluid reservoir cap stopper	1	
2	Brake fluid reservoir cap	1	
3	Brake fluid reservoir diaphragm holder	1	
4	Brake fluid reservoir diaphragm	1	
5	Brake fluid reservoir	1	
6	Brake fluid reservoir hose	1	
7	Circlip	1	
8	Dust cover	1	
9	Hose joint	1	
10	Brake lever	1	
11	Front brake switch connector	2	Disconnect.
12	Union bolt	1	Refer to "INSTALLING THE FRONT BRAKE MASTER CYLINDER".
13	Copper washer	3	



Thank you very much  
for your reading.  
Please click here  
to get more information.