

446, 456, 456s, 546, 556,  
466, 466s Silage Special  
and 566 Round Balers TM -  
All Inclusive



**TECHNICAL MANUAL**

**Round Balers 446, 546, 456, 556, 466, 566**

TM1767 21 DEC 04 (ENGLISH)



John Deere Agriculture



## Table of contents

### **FOREWORD**

### **JOHN DEERE DEALERS**

### **SERVICE TECHNICIAN RESPONSE**

#### **Section 10 - GENERAL**

- Group 05 - Safety
- Group 10 - Specifications
- Group 15 - General Information
- Group 20 - Lubricants

#### **Section 20 - DRIVE TRAIN**

- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Drive Train Protection
- Group 20 - PTO Driveline
- Group 25 - Gear Case Repair
- Group 30 - Roll Drives
- Group 35 - Rolls
- Group 40 - Miscellaneous

#### **Section 30 - HYDRAULICS**

- Group 10 - Diagnosing Malfunctions
- Group 15 - Operation and Tests-446, 456, 456S, 546 and 556
- Group 16 - Operation and Tests-466, 466S and 566
- Group 20 - Tensioning Valve Repair-446, 456, 456S, 546 and 556
- Group 21 - Tensioning Valve Repair-466, 466S and 566
- Group 25 - Gate Lock Valve Repair (456, 456S, 556, 466, 466S, and 566)
- Group 30 - Cylinder Repair-446 and 546
- Group 31 - Cylinder Repair-456, 456S and 556
- Group 32 - Cylinder Repair-466, 466S and 566
- Group 35 - Optional Hydraulic Bale Ramp Repair (456, 456S and 556)

#### **Section 40 - TWINE MECHANISM-HYDRAULIC (446, 456, 456S, 546, AND 556)**

- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Twine Wrap System Adjustments
- Group 20 - Twine Wrap System Repair

#### **Section 41 - TWINE MECHANISM-ELECTRIC**

- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Twine Wrap System Adjustments-446, 456, 456S, 546, and 556
- Group 16 - Twine Wrap System Adjustments-466, 466S, and 566
- Group 20 - Twine Wrap System Repair

#### **Section 50 - NET WRAP SYSTEM (IF EQUIPPED)**

- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Net Wrap Repair-All
- Group 16 - Net Wrap Repair-456, 456S, and 556
- Group 17 - Net Wrap Repair-466, 466S, and 566

#### **Section 60 - ELECTRICAL SYSTEM**

- Group 05 - General Information
- Group 10 - Common Electrical Tests and Checks
- Group 15 - Diagnosing Malfunctions-446, 456, 456S, 546, and 556
- Group 16 - Diagnosing Malfunctions-466, 466S, and 566
- Group 20 - Tests and Adjustments-446, 456, 456S, 546, and 556
- Group 21 - Tests and Adjustments-466, 466S, and 566

Group 25 - Electrical Diagrams-446, 456, 456S, 546, and 556

Group 26 - Electrical Diagrams-466, 466S, and 566

Group 30 - BALETRAK PLUS Monitor-Controller Operations (466, 466S, and 566)

Group 35 - Repair-446, 456, 456S, 546, and 556

Group 36 - Repair-466, 466S, and 566

Group 40 - Connector Repair

**Section 70 - PICKUP**

Group 05 - General Information

Group 10 - Diagnosing Malfunctions

Group 15 - Regular Pickup Repair

Group 16 - MEGATOOTH™ Pickup Repair

Group 17 - Wide Pickup Repair

Group 20 - Miscellaneous

**Section 80 - MISCELLANEOUS**

Group 05 - Wheel Repair

Group 10 - Gate Repair-446, 456, 456S, 546, and 556

Group 11 - Gate Repair-466, 466S, and 566

Group 15 - Tension Arm Repair-446, 456, 456S, 546, and 556

Group 16 - Tension Arm Repair-466, 466S, and 566

Group 20 - Tongue Repair

Group 25 - Belt Repair

Group 30 - Main Frame Repair





Thank you very much  
for your reading.  
Please click here  
to get more information.