

TM

Technical Manual

**John Deere
925, 935, 945,
955, 965 and 975
Combines**



TM-4307



Combines 925, 935, 945, 955, 965, and 975

Technical Manual
TM-4307 (March-76)

GENERAL 10

ENGINE 20

FUEL SYSTEM 30

ELECTRICAL SYSTEM 40

POWER TRAIN 50

BRAKES AND REAR AXLE 60

HYDRAULIC SYSTEM 70

MISCELLANEOUS 80

All information, illustrations, and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

Copyright © 1977
DEERE & COMPANY
European Office
D 68 Mannheim
All rights reserved

Printed in Germany

CUTTING PLATFORM AND CORN HEAD 100

FEEDER HOUSE 110

SEPARATOR AND CLEANING UNIT 120

**ELEVATORS, GRAIN TANK
AND UNLOADING AUGERS 130**

CONTENTS

SECTION 10 — GENERAL

- Group 5 — Specifications
- Group 10 — Pre-delivery, delivery and after-sales inspections
- Group 15 — Lubrication and periodic service
- Group 20 — Engine and combine tune-up
- Group 25 — Combine separation

SECTION 20 — ENGINE

- Group 5 — General information and diagnosing malfunctions
- Group 10 — Cylinder head, camshaft and balancer shafts
- Group 15 — Cylinder block, liners, pistons and connecting rods
- Group 20 — Crankshaft, main bearings and flywheel
- Group 25 — Timing gear train
- Group 30 — Engine lubricating system
- Group 35 — Engine cooling system
- Group 40 — Air intake system
- Group 45 — Speed control linkage

SECTION 30 — FUEL SYSTEM

- Group 5 — Diagnosing malfunctions
- Group 10 — Fuel tank, water trap, transfer pump and fuel filter
- Group 15 — Roto Diesel fuel injection pump
- Group 20 — Roosa Master fuel injection pump, "DM 4" type
- Group 25 — Roosa Master fuel injection nozzles
- Group 30 — Cold weather starting aids

SECTION 40 — ELECTRICAL SYSTEM

- Group 5 — Diagnosing malfunctions
- Group 10 — Components and wiring diagram
- Group 15 — Starting motor
- Group 20 — Alternator

SECTION 50 — POWER TRAIN

- Group 5 — Engine clutch and clutch linkage - combines 925, 935, 945
- Group 10 — Engine clutch and clutch linkage — combine 955
- Group 15 — Engine clutch - combines 965 and 975
- Group 16 — Reverser clutch, control and linkage - combines 965 and 975
- Group 20 — Front axle - combines 925, 935, 945
- Group 25 — Front axle - combines 955, 965 and 975
- Group 30 — Track system - combines 965 and 975
- Group 35 — Separator drive
- Group 40 — Variable drives
- Group 45 — POSI TORQ ground drive - combine 975

SECTION 60 — BRAKES AND REAR AXLE

- Group 5 — Parking brake combines 925, 935, 945
- Group 10 — Parking brake - combines 955, 965, 975
- Group 15 — Footbrakes
- Group 20 — Rear axle
- Group 25 — V-support for wide rear axle - combine 975

SECTION 70 — HYDRAULIC SYSTEM

- Group 5 — General information, and diagnosing malfunctions
- Group 10 — Pressure tests
- Group 15 — Hydraulic oil reservoir, filter, suction and pressure lines
- Group 20 — Hydraulic pump and flow driver
- Group 25 — Tandem (dual-gear) hydraulic pump - combines 965 and 975
- Group 30 — Single and three-spool control valves - combines 925 to 955
- Group 35 — Seven - spool control valves - combines 965 and 975
- Group 40 — Hydraulic cylinders
- Group 45 — Nitrogen accumulators
- Group 50 — Hydrostatic steering
- Group 55 — Hydraulic brakes
- Group 60 — Hydraulic clutch control-combines 965 and 975

CONTENTS (Contd.)

SECTION 100 — CUTTING PLATFORM AND CORN HEAD

- Group 5 — General information and diagnosing malfunctions
- Group 10 — Cutting platform and knife drive
- Group 15 — Corn head
- Group 20 — Corn head gear case

SECTION 110 — FEEDER HOUSE

- Group 5 — General information and diagnosing malfunctions
- Group 10 — Feeder house

SECTION 120 — SEPARATOR AND CLEANING UNIT

- Group 5 — General information and diagnosing malfunctions
- Group 10 — Threshing Cylinder
- Group 15 — Concave
- Group 20 — Beater
- Group 25 — Cross shaker
- Group 30 — Straw walkers, cleaning shoe with sieves and fan

SECTION 130 — ELEVATORS, GRAIN TANK AND GRAIN TANK UNLOADING AUGERS

- Group 5 — General information and diagnosing malfunctions
- Group 10 — Clean grain auger and elevator
- Group 15 — Lower tailings auger, elevator and upper auger
- Group 20 — Grain tank leveling auger and unloading augers
- Group 25 — Outer unloading auger and housing



Thank you very much
for your reading.
Please click here
to get more information.