

CASE

REPAIR MANUAL
SKID STEER/COMPACT TRACK LOADER

450
465
450CT
SERIES 3



87634780 NA

Issued 01Jan08

REPAIR MANUAL

**SKID STEER/
COMPACT TRACK LOADERS**

**450
465
450CT
SERIES 3**

87634780 NA

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 14

REPAIR MANUAL

**SKID STEER/
COMPACT TRACK LOADERS**

**450
465
450CT
SERIES 3**

87634780 NA

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 14

REPAIR MANUAL

**SKID STEER/
COMPACT TRACK LOADERS**

**450
465
450CT
SERIES 3**

87634780 NA

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 14

REPAIR MANUAL


**SKID STEER/
COMPACT TRACK LOADERS**

**450
465
450CT
SERIES 3**

87634780 NA

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 14



REPAIR MANUAL



450CT
450
465

Contents

INTRODUCTION

DISTRIBUTION SYSTEMS A

PRIMARY HYDRAULIC POWER SYSTEM	A.10.A
SECONDARY HYDRAULIC POWER SYSTEM	A.12.A
HIGH-FLOW HYDRAULIC POWER SYSTEM	A.16.A
ELECTRICAL POWER SYSTEM	A.30.A
LIGHTING SYSTEM	A.40.A
HYDRAULIC COMMAND SYSTEM	A.14.A

POWER PRODUCTION B

ENGINE	B.10.A
FUEL AND INJECTION SYSTEM	B.20.A
AIR INTAKE SYSTEM	B.30.A
ENGINE COOLANT SYSTEM	B.50.A
LUBRICATION SYSTEM	B.60.A
STARTING SYSTEM	B.80.A

POWER TRAIN C

POWER COUPLING Fixed coupling	C.10.B
TRANSMISSION Hydrostatic	C.20.F

TRAVELLING D

FRONT AXLE	D.10.A
REAR AXLE	D.12.A
PARKING BRAKE Hydraulic	D.32.C
WHEELS AND TRACKS Tracks	D.50.B
WHEELS AND TRACKS Wheels	D.50.C
Final drive	D.15.A
STEERING Mechanical	D.20.B

BODY AND STRUCTURE E

USER CONTROLS AND SEAT	E.32.A
USER PLATFORM	E.34.A



Thank you very much
for your reading.
Please click here
to get more information.