

# Yale Diagnostic Troubleshooting Manual #2

Download Complete Diagnostic Troubleshooting for Yale Trucks.

This Factory Diagnostic Troubleshooting Manual offers all Diagnostic information about Yale Trucks. The information on this manual covered everything you need to know when you want to repair or service Yale Trucks.

[Click Here Preview Online](#)

Models Covered:

ERC22-35VG (ERC045-070VG) [A968]; ERC16-20VA (ERC030-040VA) [A969]; ERP22-35VL (ERP045-070VL) [A976]; ERP16-20VF (ERP030-040VF) [A955]; ERP40-50VM (ERP080-100VM) [A985]; ERP15-20VT (ERP030-040VT) [G807]; ERP13VC, ERP15VC (ERP25VC, ERP30VC) [B888]; ERC40-55VH, ERC50VHS (ERC80-120VH, ERC100VHS) [A938]

Manual Contents:

SECTION 9000 – FRONT MATTER –	9000-00-1
–	9000-01-1
SECTION 9010 – OPERATIONAL DIAGNOSTIC PROCEDURES Group 05 – Operational Checkout.....	9010-05-1
SECTION 9025 – TRACTION MOTOR Group 10 – Principles of Operation.....	9025-10-1
SECTION 9030 – ELECTRICAL SYSTEM Group 03 – General Maintenance and Diagnostic Data.....	9030-03-1
Diagnostic Trouble Code (DTC) Chart.....	9030-03-6
Group 10 – Principles of Operation.....	9030-10-1
Group 20 – Diagnostic Trouble Codes.....	9030-20-1
Group 30 – Observed Symptoms.....	9030-30-1
Group 55 – Icons and Graphics.....	9030-55-1
SECTION 9035 – DRIVE AXLE/UNIT Group 10 – Principles of Operation.....	9035-10-1
Group 30 – Observed Symptoms.....	9035-30-1
SECTION 9050 – HYDRAULIC SYSTEMS Group 10 – Principles of Operation.....	9050-10-1
Group 33 – Observed Symptoms-Gear Pump.....	9050-33-1
Group 43 – Tests and Adjustments-Gear Pump.....	9050-43-1
SECTION 9060 – OPERATORS STATION Group 10 – Principles of Operation.....	9060-10-1
SECTION 9070 – FRONT END (MAST) AND CHASSIS Group 10 – Principles of Operation.....	9070-10-1
Group 30 –	

