



# 2040 Tractor



## TECHNICAL MANUAL 2040 Tractor

TM4300 (01SEP79) English



**John Deere Tractor Works**  
**TM4300 (01SEP79)**

LITHO IN U.S.A.  
ENGLISH





# 2040 TRACTOR TECHNICAL MANUAL TM-4300 (SEP-77)

## CONTENTS

### SECTION 10 - GENERAL

- Group 05 - Specifications
- Group 10 - Predelivery, Delivery, and After-Sales Inspections
- Group 15 - Lubrication and Periodic Service
- Group 20 - Engine and Tractor Tune-Up
- Group 25 - Tractor Separation (Open Center System)
- Group 26 - Tractor Separation (Closed Center System)

### SECTION 20 - ENGINE

- Group 05 - General Information, Diagnosing Malfunctions
- Group 10 - Cylinder Head and Camshaft
- Group 15 - Cylinder Block, Liners, Pistons, and Connecting Rods
- Group 20 - Crankshaft, Main Bearings, and Flywheel
- Group 25 - Timing Gear Train
- Group 30 - Engine Lubrication System
- Group 35 - Cooling System
- Group 40 - Speed Control Linkage

### SECTION 30 - FUEL SYSTEM

- Group 05 - Diagnosing Malfunctions
- Group 10 - Fuel Tank, Fuel Transfer Pump, and Air Cleaner
- Group 15 - Roto Diesel
- Group 20 - Injection Nozzles
- Group 25 - Cold Weather Starting Aid

### SECTION 40 - ELECTRICAL SYSTEM

- Group 05 - Diagnosing Malfunctions
- Group 10 - Components and Wiring Diagram
- Group 15 - Starting Motor
- Group 20 - Alternator and Regulator

### SECTION 50 - POWER TRAIN

- Group 05 - Engine Dual-Stage Clutch and Clutch Linkage
- Group 10 - Collar-Shift Transmission
- Group 15 - Differential Assembly
- Group 20 - Final Drives
- Group 25 - Continuous Running PTO

### SECTION 60 - FRONT AXLE, POWER STEERING, AND BRAKES

- Group 05 - Front Axle
- Group 10 - Power Steering (Open Center System)
- Group 11 - Power Steering (Closed Center System)
- Group 15 - Hydraulic Brakes

### SECTION 70 - HYDRAULIC SYSTEM

- Group 05 - General Information, Diagnosing Malfunctions and Tests (Open Center System)
- Group 06 - General Information, Diagnosing Malfunctions and Tests (Closed Center System)
- Group 10 - Oil Reservoir, Filter and Valves (Open Center System)
- Group 11 - Oil Reservoir, Filter and Valves (Closed Center System)
- Group 15 - Hydraulic Pump (Open Center System)
- Group 16 - Hydraulic Pump (Closed Center System)
- Group 20 - Rockshaft (Open Center System)
- Group 21 - Rockshaft (Closed Center System)
- Group 25 - Selective Control Valves (Spool Type; Open Center System)
- Group 26 - Selective Control Valves (Poppet Type; Closed Center System) and Breakaway Coupler
- Group 30 - Remote Cylinder


### SECTION 80 - MISCELLANEOUS

- Group 05 - Belt Pulley
- Group 10 - Seat
- Group 15 - Front Wheels

*All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

Copyright© 1977  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved

## INTRODUCTION



*Use FOS Manuals for Reference*

This technical manual is part of a twin concept of service:

- FOS Manuals — for reference
- Technical Manuals — for actual service

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

*Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of trouble shooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by the experienced technician.*

*Technical Manuals are concise service guides for a specific machine. Technical Manuals are on-the-job guides containing only the vital information needed by an experienced technician.*



When any serviceman should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.



*Use Technical Manuals for Actual Service*

Some features of this technical manual:

- Table of contents at front of whole Manual
- Contents at front of each Section
- Exploded views showing parts relationship
- Photos showing service techniques
- Specifications at end of each Group
- Special tools at end of each Group

This technical manual was planned and written for you — an experienced technician. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.



This safety alert symbol indicates important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

# Section 10 GENERAL

## CONTENTS OF THIS SECTION

### GROUP 5 — SPECIFICATIONS

	Page
Serial numbers . . . . .	5-2
Model numbers . . . . .	5-2
Engine . . . . .	5-2
Engine clutch . . . . .	5-2
Electrical system . . . . .	5-2
Transmission . . . . .	5-2
Differential and final drives . . . . .	5-2
Differential lock . . . . .	5-2
PTO . . . . .	5-3
Hydraulic system . . . . .	5-3
Power steering . . . . .	5-3
Hydraulic brakes . . . . .	5-3
Capacities . . . . .	5-3
Travel speeds . . . . .	5-3
Front and rear wheels . . . . .	5-3
Dimensions and weights . . . . .	5-3

### GROUP 10 — PREDELIVERY, DELIVERY AND AFTER-SALES INSPEC- TIONS

Predelivery inspection . . . . .	10-1
Delivery inspection . . . . .	10-4
After-sales inspection . . . . .	10-4

### GROUP 15 — LUBRICATION AND PERIODIC SERVICE

Lubrication and periodic service . . . . .	15-1
--	------

### GROUP 20 — ENGINE AND TRACTOR TUNE-UP

General information . . . . .	20-1
Preliminary engine testing . . . . .	20-1
Engine tune-up . . . . .	20-2
Checking engine performance . . . . .	20-3
Tractor tune-up . . . . .	20-3
Standard torques . . . . .	20-5

### GROUP 25 — TRACTOR SEPARATION (Open Center System)

	Page
Separating between engine and tractor front end . . . . .	25-1
Removing and installing engine . . . . .	25-3
Removal and installation of clutch housing . . . . .	25-4
Removal and installation of final drives . . . . .	25-6
Removal and installation of rockshaft . . . . .	25-7
Torques for hardware . . . . .	25-8
Special tools . . . . .	25-8

### GROUP 26 — TRACTOR SEPARATION (Closed Center System)

Separating between engine and tractor front end . . . . .	26-1
Removing and installing engine . . . . .	26-3
Removal and installation of clutch housing . . . . .	26-5
Removal and installation of final drives . . . . .	26-7
Removal and installation of rockshaft . . . . .	26-8
Torques for hardware . . . . .	26-9
Special tools . . . . .	26-9



Thank you very much  
for your reading.  
Please click here  
to get more information.