John Deere W540 W550 W650 W660, T550 T560 T660 T670 Combines Diagnostic Technical Manual (TM407719)

W540, W550, W650, W660, T550, T560, T660, T670 Combines Diagnostic Technical Manual (MY16, MY17, MY18, MY19)



JOHN HARE



DIAGNOSTIC TECHNICAL MANUAL W540, W550, W650, W660, T550, T560, T660, T670 Combines (MY16, MY17, MY18, MY19)

TM407719 01DEC18 (ENGLISH)



John Deere GmbH & Co. KG John Deere Werk Zweibrucken

Covers: (MY16,MY17,MY18,MY19):,W540,W550,W650,W660,T550,T560,T6

Type: Service Manual **Language:** English

Pages: 2952 Format: PDF

Features: Bookmarked, searchable, printable **Compatibility:** Windows/Mac/Tablet/Mobile

This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere W540 W550 W650 W660, T550 T560 T660 T670 Combines Diagnostic Technical Manual (TM407719)**

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.


Contents:

- · General Information
- Specifications
- · Serial Number Location
- Engine Specifications
- · Engine Diagnostics
- Engine Tests and Adjustments
- · Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- · Electrical System
- · Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- · Wheels
- · Operator's Platform
- Body Panels
- · Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- · and much more...

Please note this manual is in downloadable PDF format only. If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.	

G57 - Main Gearcase Valve Block

G57 - Main Gearcase Valve Block - Three Speed and Push Button Shift (PBST) Transmissions



H122135-UN: G57 - Main Gearcase Valve Block - Three Speed and Push Button Shift Transmission

LEGEND

A-To the Unloading Auger Engage Cylinder (C1) B-Supply from the Main Gearcase Filter Block (G33)

J-Main Gearcase Cooler (H2) Return Oil

M-Supply flow (hot oil) to the Main Gearcase Oil Cooler (H2)

B37-Main Gearcase Oil Temperature Sensor

C85-Wet Clutch

F3-Main Gearcase Filter

G33-Main Gearcase Filter Block

G53-Main Gearcase Housing

G57-Main Gearcase Valve Block

O4-Main Gearcase Lube Circuit Restriction

P1-Pressure IN

S43-Main Gearcase Filter Switch

S49-Main Gearcase Pressure Switch

V38-Filer Bypass Valve

V39-Pressure Regulating Valve

V40-Cooler Bypass Valve


V41-Lube Pressure Valve

X32-Main Gearcase Diagnostic Receptacle

Y21-Auger Engage Solenoid Valve

Y214-Separator Engage Solenoid Valve

G57 - Main Gearcase Valve Block - Two-Range Automatic Transmission





Thank you very much for your reading.

Please click here to get more information.