

**6105M, 6115M, 6125M, 6130M,
6140M, 6150M and 6170M Tractors
(Worldwide)**

**DIAGNOSIS AND TESTS
SERVICE MANUAL**

**Covered models: 6105M, 6115M,
6125M, 6130M, 6140M, 6150M,
6170M**



TM405719, May 2013



Table of contents

FOREWORD

INFORMATION ON ENGINE VERSION

Section 210 - GENERAL INFORMATION

Group 05 - Safety Measures

Group 10 - General References

Section 211 - DIAGNOSTIC TROUBLE CODES (DTC)

Group AIC - AIC Control Software

Group BLC - BLC Control Software

Group CCU - CCU Control Software

Group CRU - CRU Control Software

Group ECU_Level - ECU Level 23 Control Software

Group ECU_Level - Level 16 ECU Control Software

Group EIC - EIC Control Software

Group FCC - FCC Control Software

Group HCC - HCC Control Software

Group OIC - OIC Control Software

Group PDU - PDU Control Software

Group PTF - PTF Control Software

Group PTQ - PTQ Control Software

Group PTR - PTR Control Software

Group RPT - RPT Control Software

Group SFA - SFA Control Software

Group SMB - SMB Control Software

Group TEC - TEC Control Software

Group TEI - TEI Control Software

Group TIQ - TIQ Control Software

Group VTV - VTV Control Software

Section 212 - OBSERVABLE SYMPTOMS AND SYSTEM DIAGNOSIS

Group 20 - Engine

Group 30 - Fuel, Air Intake, and Cooling Systems

Group 40 - Electrical System

Group 45 - Electronic Control Units

Group 50A - Drive Train (without Transmission)

Group 50B - SyncroPlus™ Transmission

Group 50C - PowrReverser™ Transmission

Group 50D - PowrQuad™ Transmission

Group 60A - Steering

Group 60B - Brakes

Group 70 - Hydraulic System

Group 80A - Machine-Specific Systems

Group 80B - Suspension Systems

Group 90 - Operator's Cab

Section 220 - ENGINE

Group 20 - Exhaust Aftertreatment, Theory of Operation

Group 50 - Tests and Adjustments

Section 230 - FUEL, AIR INTAKE, AND COOLING SYSTEMS

Group 05 - General Information

Group 20A - Fuel System, Theory of Operation

Group 20B - Air Intake System, Theory of Operation

Group 20C - Cooling System, Theory of Operation

Group 20E - Cold-Weather Starting System, Theory of Operation

Group 50 - Fuel, Air Intake and Cooling Systems - Tests and Adjustments

Section 239 - FUEL, AIR INTAKE AND COOLING SYSTEMS - COMPONENT INFORMATION

- Group 40A - Fuel System, Component Information
- Group 40C - Cooling System, Component Information
- Group 40D - Charge Air Circuit, Component Information
- Group 40E - Cold-Weather Starting System, Component Information

Section 240 - ELECTRICAL SYSTEM

- Group 05 - Summary of References
- Group 50AA - 50AA - Starting Motor and Charging Circuit
- Group 50AB - 50AB - External Cold-Weather Starting Aids
- Group 50BA - 50BA - Lights/Turn-Signal Lights
- Group 50CA - 50CA - Operator's Seat
- Group 50CB - 50CB - Acoustic Alarms
- Group 50CC - 50CC - Windshield and Rear Window Wipers
- Group 50CD - 50CD - Heater/Ventilation/Air-Conditioning System
- Group 50CE - 50CE - Sockets
- Group 50CF - 50CF - Radio
- Group 50CH - 50CH - Accessories (General Information)
- Group 50EA - 50EA - TEC Control Software and Implement CAN Bus
- Group 50FA - 50FA - Electronic Engine Control
- Group 50FB - 50FB - Immobilizer
- Group 50FC - 50FC - Fuel System
- Group 50GA - 50GA - Transmission
- Group 50GE - 50GE - Front and Rear PTOs
- Group 50GG - 50GG - Brakes
- Group 50HA - 50HA - Rear Hitch
- Group 50HD - 50HD - Suspended Front-Wheel Drive Axle
- Group 50IA - 50IA - Display
- Group 50JA - 50JA - CAN Bus Systems
- Group 50X - 50X - Ground Connections

Section 245 - ELECTRONIC CONTROL UNITS

- Group 05 - Electronic Control Units - General Information
- Group 10B - Electronic Control Units - Interactive Tests and Calibrations
- Group 10C - Electronic Control Units - Information on Programming
- Group 20 - Electronic Control Units - Theory of Operation
- Group 30 - Electronic Control Units - Diagnostic Schematics
- Group 40 - Electronic Control Units - Component Information
- Group 50 - Electronic Control Units - Tests and Adjustments
- Group Immobilize - Immobilizer Control Unit
- Group AIC - AIC Control Software
- Group BLC - BLC Control Software
- Group CCU - CCU Control Software
- Group ECU_(Level - ECU Control Software (Level 23 ECU)
- Group ECU_(Level - ECU Control Software (Level 16 ECU)
- Group EIC - EIC Control Software
- Group FCC - FCC Control Software
- Group HCC - HCC Control Software
- Group OIC - OIC Control Software
- Group PDU - PDU Control Software
- Group PTF - PTF Control Software
- Group PTQ - PTQ Control Software
- Group PTR - PTR Control Software
- Group RPT - RPT Control Software
- Group SFA - SFA Control Software

Group SMB - SMB Control Software
 Group TEC - TEC Control Software
 Group TEI - TEI Control Software
 Group TIQ - TIQ Control Software
 Group VTV - VTV Control Software

Section 249 - ELECTRICAL CONNECTORS, WIRING HARNESSES AND COMPONENTS

Group 40 - Summary of Electrical Components and Harnesses
 Group 40A - Electrical Components - Assemblies
 Group 40B - Electrical Components - Sensors
 Group 40E - Electrical Components - Miscellaneous Devices and Equipment
 Group 40F - Electrical Components - Protective Equipment
 Group 40G - Electrical Components - Power Supply and Alternator
 Group 40H - Electrical Components - Monitoring and Signalling Devices
 Group 40K - Electrical Components - Relays
 Group 40M - Electrical Components - Electrical Motors
 Group 40R - Electrical Components - Resistors
 Group 40S - Electrical Components - Switches
 Group 40V - Electrical Components - Diodes
 Group 40W - Electrical Components - Wiring Harnesses
 Group 40XA - Connectors from X0001 to X0099
 Group 40XB - Connectors from X0100 to X0199
 Group 40XC - Connectors from X0200 to X0299
 Group 40XD - Connectors from X0300 to X0399
 Group 40XE - Connectors from X0400 to X0499
 Group 40XF - Connectors from X0500 to X0599
 Group 40XG - Connectors from X0600 to X0699
 Group 40XH - Connectors from X0700 to X0799
 Group 40XI - Connectors from X0800 to X0899
 Group 40XJ - Connectors from X0900 to X0999
 Group 40XK - Connectors from X1000 to X1099
 Group 40XL - Connectors from X1100 to X1199
 Group 40XM - Connectors from X1200 to X1299
 Group 40XW - Connectors and Contacts
 Group 40XX - Ground Points
 Group 40Y - Electrical Components - Solenoid Valves and Solenoids
 Group 40Z - Electrical Components - Other

Section 250A - DRIVE TRAIN (WITHOUT TRANSMISSION)

Group 10 - Drive Train (without Transmission) - Operational Checks
 Group 20 - Drive Train (without Transmission) - Theory of Operation
 Group 50 - Drive Train (without Transmission) - Tests and Adjustments

Section 250C - POWRQUAD™ TRANSMISSION

Group 05 - PowrQuad™ Transmission - General Information
 Group 10 - PowrQuad™ Transmission - Operational Checks
 Group 20 - PowrQuad™ Transmission - Theory of Operation
 Group 30 - PowrQuad™ Transmission - Schematics
 Group 50 - PowrQuad™ Transmission - Tests and Adjustments

Section 250E - POWRREVERSER™ TRANSMISSION

Group 05 - PowrReverser™ Transmission - General Information
 Group 10 - PowrReverser™ Transmission - Operational Checks
 Group 20 - PowrReverser™ Transmission - Theory of Operation
 Group 30 - PowrReverser™ Transmission - Schematics
 Group 50 - PowrReverser™ Transmission - Tests and Adjustments

Section 250F - SYNCROPLUS™ TRANSMISSION

- Group 05 - SyncroPlus™ Transmission - General Information
- Group 10 - SyncroPlus™ Transmission - Operational Checks
- Group 20 - SyncroPlus™ Transmission - Theory of Operation
- Group 30 - SyncroPlus™ Transmission - Schematics
- Group 50 - SyncroPlus™ Transmission - Tests and Adjustments

Section 259 - DRIVE TRAIN - COMPONENT INFORMATION

- Group 40A - Drive Train (without Transmission) - Component Information
- Group 40C - PowrQuad™ Transmission - Component Information

Section 260A - STEERING

- Group 05 - Steering - General Information
- Group 10 - Steering - Operational Checks
- Group 20 - Steering - Theory of Operation
- Group 50 - Steering - Tests and Adjustments

Section 260B - BRAKES

- Group 05 - Brakes - General Information
- Group 10 - Brakes - Operational Checks
- Group 20 - Brakes - Theory of Operation
- Group 30 - Brakes - Schematics
- Group 50 - Brakes - Tests and Adjustments

Section 269 - STEERING AND BRAKES - COMPONENT INFORMATION

- Group 40A - Steering - Component Information
- Group 40B - Brakes - Component Information

Section 270 - HYDRAULIC SYSTEM

- Group 05 - Hydraulic System - General Information
- Group 10 - Hydraulic System - Operational Checks
- Group 20 - Hydraulic System - Theory of Operation
- Group 20A - Oil Filter, Additional Oil Reservoir, Charge Pump and Hydraulic Pump - Theory of Operation
- Group 20B - Rear Hitch - Theory of Operation
- Group 20C - Front Hitch - Theory of Operation
- Group 20D - Selective Control Valves (SCVs) - Theory of Operation
- Group 20E - Independent Control Valves (ICVs) - Theory of Operation
- Group 30 - Hydraulic System - Schematics
- Group 50 - Hydraulic System - Tests and Adjustments

Section 279 - HYDRAULIC SYSTEM - COMPONENT INFORMATION

- Group 40 - Hydraulic System - Component Information

Section 280A - MACHINE-SPECIFIC SYSTEMS

- Group 10 - Machine-Specific Systems - Operational Checks
- Group 50 - Machine-Specific Systems - Tests and Adjustments

Section 280B - SUSPENSION SYSTEMS

- Group 10 - Suspension Systems - Operational Checks
- Group 20 - Suspended Front-Wheel Drive Axle - Theory of Operation
- Group 30 - Suspended Front-Wheel Drive Axle - Schematics
- Group 50 - Suspended Front-Wheel Drive Axle - Tests and Adjustments

Section 289 - SUSPENSION SYSTEMS - COMPONENT INFORMATION

- Group 40 - Suspended Front-Wheel Drive Axle - Component Information

Section 290 - OPERATOR'S CAB

- Group 10 - Operator's Cab - Operational Checks
- Group 20 - Operator's Cab - Theory of Operation
- Group 50 - Operator's Cab - Tests and Adjustments

Section 299 - OPERATOR'S CAB - COMPONENT INFORMATION

- Group 40 - Air Conditioning System - Component Information

Section 300 - SPECIAL TOOLS



Thank you very much
for your reading.
Please click here
to get more information.