


TILT-TATCH

S/N 678300101 & Above

SERVICE MANUAL



MELROE INGERSOLL-RAND



MAINTENANCE SAFETY





Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.





- A Cleaning and maintenance are required daily.
- Never service or adjust attachment with the engine running unless instructed to do so in manual.
- Always lower the attachment to the ground before lubricating or servicing.
- Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate skin or eyes.
- A Stop, cool and clean engine of flammable materials before checking fluids.
- Keep body, loose objects and clothing away from moving parts, electrical contacts, hot parts and exhaust.
- A Safety glasses are needed for eye protection from electrical arcs. battery acid, compressed springs, fluids under pressure and flying debris or when tools are used. Use eye protection approved for type of welding.



ALPHABETICAL INDEX

HYDRAULIC CYLINDER 10-20-1
IDENTIFICATIONiii
LEVER AND WEDGE
SERIAL NUMBER LOCATION iii SCHEMATIC 10-40-1 SPECIFICATIONS 10-40-1
TROUBLESHOOTING



Thank you very much for your reading.

Please click here to get more information.