

# 8450, 8650 and 8850 Tractor



### **TECHNICAL MANUAL**

8450, 8650 and 8850 Tractor

TM1256 (01APR85) English



John Deere Tractor Work TM1256 (01APR85)

LITHO IN U.S.A.





### 8450,8650 AND 8850 TRACTORS TECHNICAL MANUAL TM-1256 (APR-85)

#### **CONTENTS—OPERATION AND TESTS**

This manual covers Tractor Operation and Tests (yellow tabs).

Repair (green tabs) are covered in TM-1254 (8850) and TM-1255 (8450/8650).

SECTION 210-GENERAL SECTION 250-POWER TRAIN OPERATION AND Introduction and Safety Information **TESTS** Group 00—Specifications and Special Tools SECTION 220-8450/8650 ENGINE OPERATION Group 05—PERMA-CLUTCH™ Operation and AND TESTS Lubrication Group 00-Specification and Special Tools Group 10—QUAD-RANGE™ Planetary Operation Group 05--System Operation Group 15—QUAD-RANGE™ Eight-Speed Opera-Group 10-System Tests and Diagnosis Group 20—Transmission Operation and Lubrica-SECTION 225-8850 ENGINE OPERATION AND tion Circuits **TESTS** Group 25-Independent PTO Operation Group 00-Specifications and Special Tools Group 30-Torque Divider and Drive Shafts Group 05-System Operation Group 35—Differential and Final Drive Operation Group 10-System Tests and Diagnosis Group 40-Power Train Tests SECTION 230—FUEL/AIR OPERATION AND TESTS SECTION 260-STEERING/BRAKES OPERATION Group 00—Specifications and Special Tools AND TESTS Group 05-Air Intake System Group 00-Specifications and Special Tools Group 10-Diesel Fuel System Group 05—Power Steering System Operation Group 15-Control Linkage Group 10—Steering Metering Pump Operation Group 15-Steering Valve Operation SECTION 240—ELECTRICAL OPERATION AND Group 20-Steering and Feedback Cylinders **TESTS** Operation Group 00-Specifications and Special Tools Group 25 -Steering System Tests and Diagnosis Group 05-Electrical System Information Group 30-Power Brake System Operation Group 06—Phase I Wiring Diagrams Group 35-Brake Valve and Break Accumulator Group 07-Phase II Wiring Diagrams Operation Group 08—Phase III Wiring Diagrams Group 40-Brake Pistons, Plates and Disks Group 10-Electrical System Diagnosis Operation Group 15—Charging Circuit Operation Group 45—Brake System Tests and Diagnosis Group 20-John Deere Starting Circuit Group 21-Delco-Remy Starting Circuit Continued on next page

2011IIII Da on tront page

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT® 1985
DEERE & COMPANY
Moline, Illinois
All rights reserved
A JOHN DEERE ILLUSTRUCTION
Previous Editions Copyright® 1982, 1983, 1984
DEERE & COMPANY

20U;210GEN AX1 280585

Group 25-Lighting Circuit

Group 35—Accessory Circuits
Group 40—Remote Electrical Circuits

Group 30—INVESTIGATOR™ II Warning System

#### **CONTENTS—OPERATION AND TESTS—CONTINUED**

## SECTION 270—HYDRAULIC OPERATION AND TESTS


- Group 00—Specifications and Special Tools
- Group 05—Hydraulic System Operation
- Group 10—Triple Pump Assembly Operation and Tests
- Group 15—Charge Circuit Valves Operation and Tests
- Group 20—Main Hydraulic Pump Operation and Tests
- Group 25—HYDRACUSHIONED™ Seat Valve Operation and Tests
- Group 30—Pressure Control Valve Operation and Tests

- Group 35—Rockshaft System Operation and Tests Group 40—Selective Control Valve Operation and
- Tests
- Group 45—Remote Cylinder Operation and Tests Group 50—Hydraulic System Tests

## SECTION 290—OPERATOR STATION OPERATIONS AND TESTS

- Group 00—Specifications and Special Tools
- Group 05—Air Conditioning System Operation
- Group 10—Air Conditioning System Tests
- Group 15—Heating System Operation and Tests
- Group 20-HYDRACUSHIONED Seat

#### Introduction and Safety Information





Thank you very much for your reading.

Please click here to get more information.