


# John Deere 860-B Scraper





# JD860-B Scraper

Technical Manual  
TM-1171

## SECTIONAL CONTENTS OF THIS MANUAL

Section 1 - General Information	I
Section 1 - Wheels	1
Section 2 - Axles and Suspension System	2
Section 3 - Transmission	3
Section 4 - Engine	4
Section 5 - Engine Auxiliary Systems	5
Section 6 - Torque Converter	6
Section 7 - Traction (Engine) Clutch	NOT USED 7
Section 8 - Transfer Drive	NOT USED 8
Section 9 - Steering Systems	9
Section 10 - Service Brakes	10
Section 11 - Parking - Emergency Brakes	11
Section 13 - Miscellaneous Vehicle	NOT USED 13
Section 15 - Equipment Attaching	NOT USED 15

Continued on page 3

Copyright© 1977  
DEERE & COMPANY  
Moline, Illinois  
All Rights Reserved



**SECTIONAL CONTENTS (Continued)**

Section 16 - Electrical Systems _____	16
Section 17 - Frame, Chassis or Supporting Structure _____	17
Section 18 - Operator's Station _____	18
Section 19 - Sheet Metal and Styling _____	19
Section 20 - Safety, Convenience and Miscellaneous _____	20
Section 21 - Main Hydraulic System _____	21
Section 22 - Pneumatic Systems _____	NOT USED 22
Section 30 - Winch _____	NOT USED 30
Section 31 - Loader _____	NOT USED 31
Section 32 - Bulldozer _____	NOT USED 32
Section 33 - Backhoe and Excavator _____	NOT USED 33
Section 34 - Grading Device _____	NOT USED 34
Section 35 - Scraper and Haulage Device _____	35
Section 36 - Conveyor and Elevating Device _____	36
Section 37 - Arch or Boom, or Cranes _____	NOT USED 37
Section 38 - Grapple _____	NOT USED 38
Section 39 - Shear _____	NOT USED 39

Continued on page 5



Thank you very much  
for your reading.  
Please click here  
to get more information.