

9.0L Diesel Engines Level 14 Electronic Fuel System With Denso HPCR



TECHNICAL MANUAL 9.0L Diesel Engines Level 14 Electronic Fuel System with Denso HPCR

CTM385 13JUL09 (ENGLISH)

For complete service information also see:

9.0L Diesel Engines—base engine	CTM400
Alternators and Starter Motors	CTM77
OEM Engine Accessories	CTM67
	(English Only)



John Deere Power Systems
LITHO IN U.S.A.



Introduction

Forward


This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

This manual (CTM385) covers only Level 14 Electronic Fuel System with the Denso High Pressure Common Rail (HPCR). The following manual covers the base engine.

- CTM400—base engine

Other manuals will be added in the future to provide additional information on electronic fuel systems as needed.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Use this component technical manual in conjunction with the machine technical manual. An application listing in Section 01, Group 001 identifies product-model/component type-model relationship. See the machine technical manual for information on component removal and installation, and gaining access to the components.

Information is organized in sections and groups for the various components requiring service instruction. At the beginning of each group are summaries of the up coming group.

Before beginning repair on an engine, clean the engine.

This manual contains SI Metric units of measure followed immediately by the U.S. customary units of measure. Most hardware on these engines are metric sized.

Some components of this engine may be serviced without removing the engine from the machine. Refer to the specific machine technical manual for information on components that can be serviced without removing the engine from the machine and for engine removal and installation procedures.

Read each block of material completely before performing service to check for differences in procedures or specifications. Follow only the procedures that apply to the engine model number you are working on. If only one procedure is given, that procedure applies to all the engines in the manual.

CALIFORNIA PROPOSITION 65 WARNING: Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

RG41183.00000EA -19-28AUG07-1/1

Contents

Section 01—General

- Group 000—Safety
- Group 001—Engine Identification
- Group 002—Fuels, Lubricants and Coolants

Section 02—Repair and Adjustments

- Group 090—Electronic Fuel System Repair and Adjustments
- Group 100—Electronic Air System Repair and Adjustment
- Group 110—Electronic Engine Control Repair and Adjustment

Section 03—Theory Of Operation

- Group 130—Electronic Fuel System Operation
- Group 135—Electronic Air System Operation
- Group 140—Electronic Control System Operation

Section 04—Diagnostics

- Group 150—Observable Diagnostics and Tests
- Group 160—Trouble Code Diagnostics and Tests

Section 05—Tools

- Group 170—Electronic Fuel/Control System Repair Tools and Other Materials
- Group 180—Diagnostic Service Tools
- Group 190—Dealer Fabricated Service Tools

Section 06—Specifications

- Group 200—Repair Specifications
- Group 210—Diagnostic Specifications

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2008
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION © Manual
Previous Editions
Copyright © 2005, 2006, 2007

Contents

	Page
Group 000—Safety	01-000-1
Group 001—Engine Identification	
Engine Serial Number Plate	
Information.....	01-001-1
OEM Engine Option Code Label	01-001-3
Information Relative to Emissions	
Regulations.....	01-001-3
Emissions Control System	
Certification Label.....	01-001-4
Engine Application Charts	01-001-5
Group 002—Fuels, Lubricants and Coolants	
Diesel Fuel.....	01-002-1
Biodiesel Fuel.....	01-002-2
Minimizing the Effect of Cold	
Weather on Diesel Engines.....	01-002-3
Handling and Storing Diesel Fuel.....	01-002-4
Lubricity of Diesel Fuel.....	01-002-4
Testing Diesel Fuel.....	01-002-4
Engine Oil and Filter Service	
Intervals.....	01-002-4
Diesel Engine Oil.....	01-002-5
Diesel Engine Break-In Oil	01-002-5
Oil Filters	01-002-6
OILSCAN™ and COOLSCAN™.....	01-002-6
Grease.....	01-002-7
Alternative and Synthetic	
Lubricants.....	01-002-7
Lubricant Storage.....	01-002-7
Mixing of Lubricants.....	01-002-8
Heavy Duty Diesel Engine	
Coolant	01-002-8
Supplemental Coolant Additives.....	01-002-9
Operating in Warm Temperature	
Climates.....	01-002-9
Additional Information About	
Diesel Engine Coolants and	
John Deere LIQUID COOLANT	
CONDITIONER	01-002-10
Diesel Engine Coolant.....	01-002-11
Testing Diesel Engine Coolant.....	01-002-11
Drain Intervals for Diesel Engine	
Coolant	01-002-12



Thank you very much
for your reading.
Please click here
to get more information.