

Seeder

72 Inch



Bobcat®


Service Manual

(72 In) S/N 018000101 & Above

PDF



DOWNLOAD



CONTENTS

ATTACHMENT DELIVERY REPORT	III
IDENTIFICATION AND MACHINE SIGNS (DECALS)	IV
SERIAL NUMBER LOCATION	III
SAFETY AND MAINTENANCE.....	10-01
MAIN FRAME	20-01
SPECIFICATIONS.....	SPEC-01

**SAFETY AND
MAINTENANCE**

**MAIN
FRAME**


**SPECIFICATIONS
AND
SCHEMATICS**



Bobcat®

SERIAL NUMBER LOCATION


Figure 1



Always use the serial number of the Seeder when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation [Figure 1].

ATTACHMENT DELIVERY REPORT

Figure 2



The Attachment Delivery Report must be filled out by the dealer and signed by the owner or operator when the Seeder is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely [Figure 2].



Thank you very much
for your reading.
Please click here
to get more information.