



Please cut where indicated and insert the label into the plastic pocket on the spine of the binder.



**COMBINE  
REPAIR**

**TR®96, TR®97,  
TR®98**

**Vol. 1  
40009630**



**COMBINE  
REPAIR**

**TR®96, TR®97,  
TR®98**

**Vol. 2  
40009630**



# **TR96, TR97, TR98 COMBINE REPAIR MANUAL CONTENTS**

SECTION 0 - GENERAL AND SAFETY INFORMATION
SECTION 1 - ELECTRICAL SYSTEM
SECTION 2- HYDRAULIC SYSTEM
SECTION 3- MONITOR SYSTEM
SECTION 4- SEPARATOR CLUTCH
SECTION 5- ENGINE PTO
SECTION 6- FEEDER
SECTION 7- ROTOR DRIVE
SECTION 8- ROTORS
SECTION 9- ROTOR GEARBOXES
SECTION 10 - CONCAVES
SECTION 11 - SEPARATOR GRATES
SECTION 12 - DISCHARGE BEATER AND GRATE
SECTION 13 - CLEANING FAN
SECTION 14 - CLEANING SHOE
SECTION 15 - CLEAN GRAIN AND FILLING SYSTEM
SECTION 16 - TAILINGS SYSTEM
SECTION 17 - UNLOADING SYSTEM
SECTION 18 - MAIN SHAFT
SECTION 19 - HYDROSTATIC SYSTEM
SECTION 20 - TRANSMISSION
SECTION 21 - POWERED REAR AXLE
SECTION 22 - FINAL DRIVES
SECTION 23 - BRAKES
SECTION 24 - CYLINDERS

---

# **TR<sup>®</sup>96, TR<sup>®</sup>97, TR<sup>®</sup>98 COMBINE REPAIR MANUAL**

## **INTRODUCTION**

This repair manual provides you with the technical information needed to properly service the TR96, TR97, and TR98 combines. By using this repair manual in addition to the operator's manual supplied with the combine, you should be able to correctly service and maintain the combine.

On New Holland equipment, left and right are determined by standing behind the unit, looking in the direction of travel.

This manual describes the procedures of removal, disassembly, reassembly, etc., that have been found to be the easiest and least time-consuming. There may be several other ways of completing the same job, but it has been established that the described methods are best. Modifications to these procedures are your own decision.

Certain hardware on the combine must be tightened to particular torque specifications. If there are no specific torque specifications for the hardware, tighten to the torque listed in the torque charts in this section of the manual.



**CAUTION!**

**CAUTION: PICTURES IN THIS MANUAL MAY SHOW PROTECTIVE SHIELDING OPEN OR REMOVED TO BETTER ILLUSTRATE A PARTICULAR FEATURE OR ADJUSTMENT.**

**BE CERTAIN, HOWEVER, TO CLOSE OR REPLACE ALL SHIELDING BEFORE OPERATING THE MACHINE.**

## **IMPROVEMENTS**

New Holland North America, Inc. is continually striving to improve its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

**ALL SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE.**





Thank you very much  
for your reading.  
Please click here  
to get more information.