

### E80MSR

# WORKSHOP MANUAL ENGLISH

Print No. 604.13.421



Edition 02/2005 English - Printed in Italy

#### TO THE READER

 This manual has been written for a skilled technician, in order to give him the information necessary to repair this machine.

Read this manual carefully for correct information about repair procedures.

For any question or comment, or in case you notice a mistake in this manual content, please contact:

NEW HOLLAND KOBELCO CONSTRUCTION MACHINERY S.p.A. Strada di Settimo, 323 San Mauro Torinese (TO) 10099 ITALIA PRODUCT SUPPORT Fax. ++39 011 0077357

#### ADDITIONAL REFERENCE MANUALS

In addition to this Workshop Manual, refer also to the following:

Operation and maintenance instruction manual Spare parts catalog

# DESCRIPTION OF THE WORKSHOP MANUAL

 This repair manual consists of one single volume, identified with:

E80MSR - Workshop Manual "Hydraulic exavator"

- The "Hydraulic exavator" Workshop Manual contains the technical information necessary for machine service and repair, the service equipment, the information on maintenance standards, the removal and installing procedures, and the disassembly and assembly procedures.
- The complete Workshop Manual for the model E80MSR consists of the following volume identified by print number as shown herebelow:

VOLUME	MACHINE TYPE	PRINT No.
Workshop Manual - "Hydraulic exavator"	E80MSR	604.13.421

### **AVOID ACCIDENTS**

Most accidents, whether they occur in industry, on the farm, at home or on the highway, are caused by the failure of some individuals to follow simple and fundamental safety rules or precautions. For this reason MOST ACCIDENTS CAN BE PREVENTED by recognising the real cause and doing something about it before the accident occurs.

Regardless of the care used in the design and construction of any type of equipment there are conditions that cannot be completely safeguarded against without interfering with reasonable accessibility and efficient operation.

Carefully read indications, cautions and safety warning quoted in the "SAFETY RULES" section.

A careful operator is the best insurance against an accident.

The complete observance of one simple rule would prevent many thousand serious injuries each year.

That rule is:

Never attempt to clean, oil or adjust a machine while it is in motion.

### **A** ATTENTION

On machines having hydraulically, mechanically and/or cable controlled equipment (such as showels, loaders, dozers, scrapers etc.) be certain the equipment is lowered to the ground before servicing, adjusting and/or repairing.

If it is necessary to have the equipment partially or fully raised to gain access to certain items, be sure the equipment is suitably supported by means other than the hydraulic lift cylinders, cable and/or mechanical device used for controlling the equipment.

### COPYRIGHT BY NEW HOLLAND KOBELCO CONSTRUCTION MACHINERY S.p.A.

**Product Support - Documentation Centre** 

Strada di Settimo, 323 - 10099 S. Mauro T.SE (TO) ITALY

All rights reserved. Reproduction of text and illustrations in whole or in part, is strictly prohibited.



Thank you very much for your reading.

Please click here to get more information.