

**John Deere Agriculture**

**5310, 5050E, 5210, 5055E, 5060E, 5065E and  
5075E Tractors**

**TECHNICAL MANUAL**

**5310, 5050E, 5210, 5055E, 5060E, 5065E, 5075E**



**TM900619, July 2013**



# Table of contents

## **FOREWORD**

### **Section 10 - GENERAL INFORMATION**

- Group 05 - Safety
- Group 10 - General Specifications
- Group 20 - Fuel and Lubricants
- Group 25 - Serial Number Locations
- Group 30 - Features and Accessories

### **Section 20 - ENGINE REPAIR**

- Group 05 - Engine
- Group 10 - Cylinder Head and Valves
- Group 15 - Cylinder Block, Liners, Pistons and Rods
- Group 20 - Crankshaft, Main Bearings and Flywheel
- Group 25 - Camshaft and Timing Gear Train
- Group 30 - Lubrication System
- Group 35 - Cooling System

### **Section 30 - FUEL AND AIR INTAKE SYSTEM REPAIR**

- Group 05 - Fuel System
- Group 10 - Air Intake and Exhaust System
- Group 15 - Speed Control Linkage

### **Section 40 - ELECTRICAL REPAIR**

- Group 05 - Battery, Starter and Alternator
- Group 10 - Electrical System Components
- Group 15 - Wiring Harness

### **Section 50 - POWER TRAIN REPAIR**

- Group 05 - Clutch Housing
- Group 10 - Clutch Assembly
- Group 15 - Transmission
- Group 20 - Rear PTO Drive Shaft
- Group 25 - Differential
- Group 30 - Final Drives
- Group 35 - Mechanical Front Wheel Drive - If Equipped

### **Section 60 - STEERING AND BRAKE REPAIR**

- Group 05 - Steering Repair
- Group 10 - Brake Repair

### **Section 70 - HYDRAULIC REPAIR**

- Group 05 - Hydraulic Pump and Filter
- Group 10 - JD Rockshaft
- Group 15 - Selective Control Valve (SCV)

### **Section 80 - MISCELLANEOUS REPAIR**

- Group 05 - Front Axle
- Group 10 - Wheels
- Group 15 - 3-Point Hitch
- Group 20 - Hood
- Group 25 - Cowl

### **Section 90 - OPERATOR STATION REPAIR**

- Group 05 - Seat and Support
- Group 06 - Center Console
- Group 15 - Operator Platform
- Group 20 - Fenders

Group 25 - Roll-GardROLL-GARD is a trademark of Deere & Company.

**Section 210 - OPERATIONAL CHECKOUT PROCEDURES**

Group 10 - Operational Checkout Procedures

**Section 220 - ENGINE OPERATION, TESTS AND ADJUSTMENTS**

Group 05 - Component Location

Group 10 - Theory of Operation

Group 15 - Diagnosis, Tests and Adjustments

**Section 230 - FUEL/AIR OPERATION, TESTS AND ADJUSTMENTS**

Group 05 - Component Location

Group 10 - Theory of Operation

Group 15 - Diagnosis, Tests and Adjustments

**Section 240 - ELECTRICAL SYSTEM OPERATION, TESTS AND ADJUSTMENTS**

Group 05 - Component Location

Group 10 - Theory of Operation

Group 15 - Diagnosis, Tests and Adjustments

Group 20 - Wiring Schematics

Group 25 - Component Information—Connectors

**Section 250 - POWER TRAIN OPERATION, TESTS AND ADJUSTMENTS**

Group 05 - Component Location

Group 10 - Theory of Operation

Group 15 - Diagnosis, Tests and Adjustments

**Section 260 - STEERING AND BRAKE OPERATION, TESTS & ADJUSTMENTS**

Group 05 - Component Location

Group 10 - Theory of Operation

Group 15 - Diagnosis, Tests and Adjustments

**Section 270 - HYDRAULIC SYSTEM OPERATION, TESTS AND ADJUSTMENTS**

Group 05 - Component Location

Group 10 - Theory of Operation

Group 15 - Diagnosis

Group 20 - Hydraulic Tests - Without SCV

Group 25 - Hydraulic Tests—With SCV

Group 30 - Hydraulic Tests - All

Group 40 - Adjustments

Group 45 - Hydraulic Schematics



## Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

---

### **CAUTION:**

---

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.



Thank you very much  
for your reading.  
Please click here  
to get more information.