



645

SERVICE MANUAL



MAINTENANCE SAFETY




WARNING


Instructions are necessary before operating or servicing machine. Read Operation & Maintenance Manual, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Failure to follow instructions can cause injury or death.

W-2003-1089


! Safety Alert Symbol: This symbol is used for important safety messages. When you see this symbol, follow the safety message to avoid personal injury or death.



! Never service the Bobcat loader without instructions.



! Use the correct procedure to lift or lower operator cab.



! Cleaning and maintenance are required daily.



! Have good ventilation when welding or grinding painted parts. Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.



! Keep rear door closed except for service. Close and latch door before operating the loader.



! Never work on loader with lift arms up unless lift arms are held by a lift arm support device.

! Never modify equipment or add attachments not approved by Melroe Company.



Thank you very much
for your reading.
Please click here
to get more information.