





## Shop Manual DX300LC-5 Excavator

## Serial Number 1001 and Up Serial Number 50001 and Up

DOOSAN and the DOOSAN logo are registered trademarks of DOOSAN Corporation in the United States and various other countries around the world.



950106-00980E February 2014

## Installing the Oil Cooler

- Clean the gasket faces on the cylinder block and oil cooler cover.
- 2. Install the oil cooler cover (1) with a new gasket.
- 3. Install the lower coolant hose (2).
- 4. Install the oil filter housing (3) with a new gasket and new




Figure 321

- Install the clamp of the turbocharger cable harness (4). 5.
- Install the oil pressure sensor (5) and the coolant 6. temperature sensor (6).
- Install the hose and coolant pipe (7) on the water-cooled 7. EGR cooler.
- 8. Install the turbocharger.
- 9. Fill and bleed the cooling system.




Figure 322

DX300LC-5 Engine 4-1-171




Figure 5



Thank you very much for your reading.

Please click here to get more information.