

2011 Doosan DX340LCA Crawled Excavator Service Repair Workshop Manual



PDF



DOWNLOAD



DX340LCA

Shop Manual

950106-00268E

Serial Number 5001 and Up

DOOSAN reserves the right to improve our products in a continuing process to provide the best possible product to the market place. These improvements can be implemented at any time with no obligation to change materials on previously sold products. It is recommended that consumers periodically contact their distributors for recent documentation on purchased equipment.

This documentation may include attachments and optional equipment that is not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.



Figure 90

3. Put the prepared carrier assembly No.1 on the assembling part and turn it clockwise or anticlockwise lightly for it to engage with the low toothed shaft end of the ring gear and the sun gear No.2.



Figure 91



Figure 92

4. Insert the sun gear No.1 in the middle of the carrier No.1.



Figure 93



Figure 79



Figure 80

Assembly of the Ring Gear

1. Press fitting of the lock pin

Insert lock pins ($\varnothing 13 \times 31.5$) in 4 reamer holes of the casing and use a hammer to tap them.



Figure 81




Figure 82



Thank you very much
for your reading.
Please click here
to get more information.