

KOMATSU PW200-7K,PW220-7K Wheeled Excavators Service Repair Workshop Manual[UEBM001901]



SHOP MANUAL

KOMATSU

PW200-7K PW220-7K

MACHINE MODEL

PW200-7K

PW220-7K

SERIAL NUMBER

K40001 AND UP

K40001 AND UP

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PW200/PW220-7K mount the SAA6D102E-2 engine. For details of the engine, see the 102 Series Engine Shop Manual.

CONTENTS

	No. of page
01 GENERAL	01-1
10 STRUCTURE, FUNCTION AND MAINTENANCE STANDARD	10-1
20 TESTING AND ADJUSTING	20-1
30 DISASSEMBLY AND ASSEMBLY	30-1
90 OTHERS	90-1

20. Lubricate the threads of the steering cylinder with grease.



21. Screw heads of steering cylinder (6).



22. Fit screws (5). Torque = 117Nm (12 kgf-m)




23. Assemble steering bars (3).



24. Assemble joint pivots (2) and thicknesses (4).



25. Assemble safety split pins (1).





Thank you very much
for your reading.
Please click here
to get more information.