



# SERVICE MANUAL



# SHOP MANUAL

## **KOMATSU**

# **WA470-5**

# **WA480-5**

MACHINE MODEL	SERIAL NUMBER
---------------	---------------

<b>WA470-5</b>	<b>70001 and up</b>
----------------	---------------------

<b>WA480-5</b>	<b>80001 and up</b>
----------------	---------------------

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require.  
Materials and specifications are subject to change without notice.
- WA470-5, WA480-5 mounts the SAA6D125E-3 engine.  
For details of the engine, see the 125-3 Series Engine Shop Manual.

# CONTENTS

	No. of page
<b>01 GENERAL</b> .....	01-1
<b>10 STRUCTURE, FUNCTION AND MAINTENANCE STANDARD</b> .....	10-1
<b>20 TESTING AND ADJUSTING</b> .....	20-1
<b>30 DISASSEMBLY AND ASSEMBLY</b> .....	30-1
<b>90 OTHERS</b> .....	90-1

# Shop Manual

## Part I

VEBM180101

# WA470-5H

# WA480-5H

## WHEEL LOADER

### MODEL

WA470-5H  
WA480-5H

### SERIAL NUMBER

WA470H50051 AND UP  
WA480H50051 AND UP

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local KOMATSU distributor for those items you may require. Materials and specifications are subject to change without notice.
- WA470-5 and WA480-5 mount the SAA6D125-3 engine. For details of the engine, see the 125-3 Series Engine Shop Manual



Thank you very much  
for your reading.  
Please click here  
to get more information.