

Komatsu Wheel Loaders WA500-1 Service Repair Workshop Manual



SHOP MANUAL

KOMATSU

WA500-1

MACHINE MODEL SERIAL No.

WA500-1 10001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- WA500-1 mount the S6D140-1 engine;
For details of the engine, see the 6D140-1 Series Engine Shop Manual.

CONTENTS

10 ENGINE

	No. of page
11 STRUCTURE AND FUNCTION	11-1
12 TESTING AND ADJUSTING	12-1
13 DISASSEMBLY AND ASSEMBLY	13-1
14 MAINTENANCE STANDARD	14-1

20 POWER TRAIN

21 STRUCTURE AND FUNCTION	21-1
22 TESTING AND ADJUSTING	22-1
23 DISASSEMBLY AND ASSEMBLY	23-1
24 MAINTENANCE STANDARD	24-1

40 STEERING SYSTEM

41 STRUCTURE AND FUNCTION	41-1
42 TESTING AND ADJUSTING	42-1
43 DISASSEMBLY AND ASSEMBLY	43-1
44 MAINTENANCE STANDARD	44-1

50 BRAKE AND AIR SYSTEM

51 STRUCTURE AND FUNCTION	51-1
52 TESTING AND ADJUSTING	52-1
53 DISASSEMBLY AND ASSEMBLY	53-1
54 MAINTENANCE STANDARD	54-1

60 WORK EQUIPMENT SYSTEM

61 STRUCTURE AND FUNCTION	61-1
62 TESTING AND ADJUSTING	62-1
63 DISASSEMBLY AND ASSEMBLY	63-1
64 MAINTENANCE STANDARD	64-1

80 ELECTRIC AND ELECTRONIC SYSTEM

81 STRUCTURE AND FUNCTION	81-1
82 TESTING AND ADJUSTING	82-1
83 DISASSEMBLY AND ASSEMBLY	83-1

90 OTHERS

91 OTHERS	91-1
93 DISASSEMBLY AND ASSEMBLY	93-1
97 GEAR PUMP	97-101

SHOP MANUAL

KOMATSU WA500-1

MACHINE MODEL	SERIAL No.
WA500-1	20001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- WA500-1 mount the S6D140-1 engine;
For details of the engine, see the 6D140-1 Series Engine Shop Manual.



Thank you very much
for your reading.
Please click here
to get more information.