

File has expired.

Use updated files from Bobcat
Publications.



File has expired.

Use updated files from Bobcat
Publications.

MAINTENANCE SAFETY



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow

follow
03-0903

ty is

LONG

B-15547

ing any
fitting,
can cause
under lift
supported
support
1.

LONG

B-6673

lift arms
ld by an
evice.
or add
ved by

LONG

B-6589

produce
ases.
es and
from

ch burns
t. Wear
contacts
. For eye
nd get



Keep rear door closed except for
service. Close and latch door
before operating the loader.

immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use **genuine Bobcat replacement parts**. The Service Safety Training Course is available from your Bobcat dealer.

MSW04-0805

Dealer Copy -- Not for Resale

File has expired.

Use updated files from Bobcat
Publications.



Thank you very much
for your reading.
Please click here
to get more information.