

8120T, 8220T, 8320T, 8420T, and 8520T Tractors Operation and Test

TECHNICAL MANUAL 8120T, 8220T, 8320T, 8420T and 8520T Tractors Operation and Test

TM1981 15JUL10 (ENGLISH)

For complete service information also see:

8120T, 8220T, 8320T, 8420T, and 8520T Tractors Repair	TM1971
POWERTECH™ 8.1L Diesel Engines - Level 9 Electronic Fuel Systems With Denso In Pump.....	
POWERTECH™ 8.1L Diesel Engines - Base Engine.....	
Alternators and Starters	
Real Time Kinematics(RTK) Base Station Diagnosis and Tests.....	TM2820




Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX, TMIFC -19-29SEP98-1/1

Contents

Section 210—GENERAL

- Group 05—Safety
- Group 15—General References

Section 211—SERVICE CODES

- Group ACU—ACU Code Diagnostics
- Group AMS—AMS General Diagnostic Codes
- Group ATC—ATC Code Diagnostics (902001—)
- Group CCU—CCU Code Diagnostics
- Group ECU—ECU Code Diagnostics
- Group HCU—HCU Code Diagnostics
- Group ICU—ICU Code Diagnostics
- Group JDL—JdL Code Diagnostics
- Group PCU—PCU Code Diagnostics
- Group SCU—SCU Code Diagnostics
- Group SCo—SCo Code Diagnostics
- Group SSU—SSU Code Diagnostics
- Group SUP—SUP Code Diagnostics

Section 212—OBSERVABLE SYMPTOMS

- Group 15—Electrical
- Group 16—Ag Management Solutions (AMS)
- Group 20—Hitch
- Group 25—Heating, Ventilation and Air Conditioning (Standard)
- Group 26A—Heating, Ventilation and Air Conditioning - CLIMATRAK™ (ATC) (—902000)
- Group 26B—Heating, Ventilation and Air Conditioning - CLIMATRAK™ (ATC) (902001—)
- Group 30—Operator Station
- Group 40—Power Take-Off (PTO)
- Group 45—Selective Control Valves (SCV)
- Group 50—Steering
- Group 55—Transmission
- Group 70—Hydraulics

Section 213—SYSTEM DIAGNOSIS

- Group 40—Electrical
- Group 50—Transmission System
- Group 60—Steering and Brakes System
- Group 70—Hydraulic System
- Group 90—CLIMATRAK™ (ATC) System (902001—)
- Group 90F—Heated Seat

Section 220—ENGINE

- Group 10—Operational Checks
- Group 15—Tests and Adjustments
- Group 20—Theory of Operation

- Group 25—Schematics and Diagrams

Section 230—FUEL AND AIR

- Group 20—Theory of Operation

Section 240—ELECTRICAL

- Group 15—Tests and Adjustments
- Group 20—Theory of Operation
- Group 25—Schematics and Diagrams

Section 245—CONTROL UNITS

- Group 05—Codes and Addresses
- Group ACU—ACU References
- Group ATC—CLIMATRAK™ (ATC) References
- Group CCU—CCU References
- Group ECU—ECU References
- Group HCU—HCU References
- Group ICU—ICU References
- Group IMS—Implement Management System (IMS) References
- Group PCU—PCU References
- Group SCU—SCU References
- Group SCo—SCo References
- Group SSU—SSU References
- Group SUP—SUP References

Section 246A—AG MANAGEMENT SOLUTIONS (AMS) — GREENSTAR™

- Group GSS—GREENSTAR™ System References

Section 246B—AG MANAGEMENT SOLUTIONS (AMS)—JDLINK™

- Group 10A—Accessing Diagnostic Addresses and Codes
- Group 10B—Diagnostic Trouble Codes
- Group 10C—Diagnostic Addresses
- Group 15A—JDLINK™ Machine Messenger Diagnostics

Section 246C—AG MANAGEMENT SOLUTIONS (AMS) — AUTOTRAC

- Group 5A—How to Use This Diagnostic Information
- Group 10A—Accessing Diagnostic Addresses and Codes
- Group 10B—Diagnostic Trouble Codes
- Group 10C—Diagnostic Addresses

Continued on next page

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2010
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION © Manual
Previous Editions
Copyright © 2001, 2002, 2003, 2004, 2005, 2006, 2008, 2009

- Group 15A—AutoTrac Identification
- Group 15B—AutoTrac Diagnostics - 8000 Series
Factory Installed
- Group 15C—AutoTrac Diagnostics - 8000 Series Field
Installed
- Group 15D—GREENSTAR™ Parallel Tracking
Identification
- Group 15E—Parallel Tracking Diagnostics - 8000
Series Factory Installed
- Group 15F—Parallel Tracking Diagnostics - 8000
Series Field Installed
- Group 15G—GREENSTAR™ Display Diagnostics
- Group 15H—GREENSTAR™ Mobile Processor
Diagnostics
- Group 15I—STARFIRE™ Receiver Diagnostics
- Group 15J—GREENSTAR™ KeyCard Diagnostics
- Group 15K—AutoTrac CAN Bus Identification
- Group 15L—AutoTrac CAN Bus Diagnostics - 8000
Series Factory Installed
- Group 15M—AutoTrac CAN Bus Diagnostics - 8000
Field Installed
- Group 15N—AutoTrac CCD Bus Identification
- Group 15O—AutoTrac CCD Bus Diagnostics - 8000
Series Factory Installed
- Group 15P—AutoTrac CCD Bus Diagnostics - 8000
Series Field Installed
- Group 15Q—AutoTrac Power Identification
- Group 15R—AutoTrac Power Diagnostics - 8000
Series Factory Installed
- Group 15S—AutoTrac Power Diagnostics - 8000 Series
Field Installed
- Group 15T—AutoTrac Status Identification
- Group 15U—AutoTrac Status Diagnostics - 8000
Series Factory Installed
- Group 15V—AutoTrac Status Diagnostics - 8000 Series
Field Installed
- Group 15W—AutoTrac Steering Response
Identification
- Group 15X—AutoTrac Steering Response Diag. - 8000
Series Factory Installed
- Group 15Y—AutoTrac Steering Response Diag. - 8000
Series Field Installed
- Group 15Z—AutoTrac Steering Control Unit
Identification
- Group 15AA—AutoTrac Steering Control Unit Diag -
8000 Series Factory Installed
- Group 15AB—AutoTrac Steering Control Unit Diag -
8000 Series Field Installed
- Group 20A—Circuit Code Listing
- Group 20B—Connector Information

**Section 246D—AG MANAGEMENT
SOLUTIONS (AMS) - FIELD DOC**

- Group 15A—GPS Position and STARFIRE Receiver
Operation and Tests
- Group 15B—FIELD DOC Basic Operation and Tests

Section 250—POWERSHIFT TRANSMISSION

- Group 10—Operational Checks
- Group 15—Tests and Adjustments
- Group 20—Theory of Operation
- Group 25—Schematics and Diagrams

Section 256—DRIVE SYSTEMS

- Group 15—Tests And Adjustments
- Group 20—Theory of Operation

Section 260—STEERING AND BRAKES

- Group 05—Preliminary Checks
- Group 10—Operational Checks
- Group 15—Tests and Adjustments
- Group 20—Theory of Operation
- Group 25—Schematics and Diagrams

Section 270—HYDRAULICS

- Group 10—Operational Checks
- Group 15—Tests and Adjustments
- Group 20—Theory of Operation
- Group 25—Schematics and Diagrams

Section 290—OPERATOR STATION

- Group 05—Preliminary Checks
- Group 10—Operational Checks
- Group 15—Tests And Adjustments
- Group 20—Theory Of Operation
- Group 25—Schematics and Diagrams

Section 299—TOOLS

- Group 10—Fabricated Tools
- Group 15—Test Kits

Contents

	Page
Group 05—Safety	210-05-1
Group 15—General References	
Reference 210-15-001, General Reference List	210-15-1
Reference 210-15-002, Bolt and Cap Screw Torque Values	210-15-2
Reference 210-15-003, Glossary of Terms	210-15-4
Reference 210-15-004, JIC Hydraulic Symbols	210-15-8
Reference 210-15-005, Wiring Diagram and Schematic Information	210-15-10
Reference 210-15-006, Electrical Schematic Symbols	210-15-12
Reference 210-15-007, Reading Wiring Schematics and Drawings	210-15-14
Reference 210-15-008, Visually Inspect Electrical System	210-15-17
Reference 210-15-009, Seven Step Electrical Procedure ¹	210-15-18
Reference 210-15-010, Using a Probe Light	210-15-20
Reference 210-15-011, Circuit Types	210-15-21
Reference 210-15-012, Circuit Malfunctions	210-15-23
Reference 210-15-013, Troubleshooting Circuit Malfunctions	210-15-26
Reference 210-15-014, Understanding Electrical vs. Electronic Circuits	210-15-30
Reference 210-15-015, Intermittent Electronic Problems	210-15-32
Reference 210-15-016, Relay Circuit Types	210-15-35
Reference 210-15-017, Using a Digital Multimeter	210-15-48



Thank you very much
for your reading.
Please click here
to get more information.