


John Deere 640L, 648L, 748L (SN.C666893◆◆◆◆◆◆◆◆690813; D679126◆◆◆◆◆◆◆◆690813) Skidder Diagnostic Manual TM13135X19

Section 9025 - HYDRAULIC SYSTEM

Group 15: Diagnostic Information

Travel System Component Location



TX1002232

Travel System Component Location

LEGEND:

- | | |
|----|----------------------------|
| 15 | Pump 1 (right) |
| 16 | Pump 2 (left) |
| 28 | Pilot Pump |
| 31 | Hydraulic Oil Tank |
| 38 | Travel Pilot Control Valve |
| 41 | Pilot Signal Manifold |

Go to Section TOC

Section 9025 page 237

380GLC Excavator Diagnostic

Covers: 640L,C666893◆◆◆◆◆◆◆◆690813;;D679126◆◆◆◆◆◆◆◆690813),64

Type: Service Manual

Language: English

Pages: 1270

Format: PDF

Features: Bookmarked, searchable, printable

Compatibility: Windows/Mac/Tablet/Mobile

This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere 640L, 648L, 748L (SN.C666893◆◆◆◆◆◆◆◆◆◆690813; D679126◆◆◆◆◆◆◆◆◆◆690813)**

Skidder Diagnostic Manual TM13135X19

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.

Contents:

- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...

Please note this manual is in **downloadable PDF format only**. If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

Fuse and Relay Specifications




Relay and Fuse Block Component Location

LEGEND:

- | | |
|---|--------------|
| 1 | Relay Block |
| 2 | Fuse Block 1 |
| 3 | Fuse Block 2 |

Fuse Block 1





Thank you very much
for your reading.
Please click here
to get more information.