


John Deere W540, W550, W650, W660, T550, T560, T660, T670 Combines (MY14) Diagnostic Manual TM406119



Covers: 1Z0);W540,W550,W650,W660,T550,T560,T670,T660

Type: Service Manual

Language: English

Pages: 4110

Format: PDF

Features: Bookmarked, searchable, printable

Compatibility: Windows/Mac/Tablet/Mobile

This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere W540, W550, W650, W660, T550, T560, T660, T670 Combines (MY14) Diagnostic Manual TM406119**

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.

Contents:

- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...


Please note this manual is in **downloadable PDF format only**. If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

MISCELLANEOUS REPAIR

Remove and Install Rear Drive Wheels

Removal


1. Park machine on a level surface and set park brake.



MX18190

2. Slightly loosen four wheel nuts (A).

IMPORTANT: Avoid damage! Do not use rear grille as a lift point; this could damage the frame.




MX18190

3. Lift machine with a safe lifting device centered under tire support frame (B) on the side the tire is being removed.
4. Remove wheel nuts.
5. Remove wheel.

Installation

1. Install wheel.



MX10207

2. Install and tighten wheel nuts in numbered sequence shown for safe wheel installation. Tighten alternately until specification is reached.
3. Lower machine.
4. Inflate tires to specification.

Specifications

Rear (Drive) Wheel Nut Torque 100 N·m (75 lb-ft)

Tire Air Pressure (Drive) 69-97 kPa (10-14 psi)

Remove and Install ROPS

Removal



MX20052

1. Remove the rear grille
 - Loosen two cap screws (A).
 - Lift the grille up slightly at the rear and slide back to remove.



Thank you very much
for your reading.
Please click here
to get more information.