

Bobcat®

Service Manual

S/N 514440001 & Above

S/N 514540001 & Above

S/N 514640001 & Above



DOWNLOAD



EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS™)



MAINTENANCE SAFETY



WARNING


Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.


CORRECT



B-10731a

- Never service the Bobcat Skid-Steer Loader without instructions.


CORRECT



B-15590

- Use the correct procedure to lift or lower operator cab.


CORRECT



B-15591

- Cleaning and maintenance are required daily.


WRONG



B-15592

- Have good ventilation when welding or grinding painted parts.
- Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.
- Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.


WRONG



B-15593

- Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.


WRONG



B-15599

- Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.
- Never modify equipment or add attachments not approved by Bobcat Company.


WRONG



B-15600

- Stop, cool and clean engine of flammable materials before checking fluids.
- Never service or adjust loader with the engine running unless instructed to do so in the manual.
- Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
- Never fill fuel tank with engine running, while smoking or when near open flame.

WRONG



B-15601

- Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
- Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.
- Keep rear door closed except for service. Close and latch door before operating the loader.

WRONG



B-6589

- Lead-acid batteries produce flammable and explosive gases.
- Keep arcs, sparks, flames and lighted tobacco away from batteries.
- Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.



Bobcat®

ALPHABETICAL INDEX

ADVANCED CONTROL SYSTEM		ENGINE LUBRICATION SYSTEM	10-01
(ACS) ADVANCED HAND CONTROL	60-01	ENGINE SPECIFICATIONS	SPEC-01
ADVANCED CONTROL SYSTEM		ENGINE SPEED CONTROL	70-01
(ACS) SELECTABLE HAND/FOOT CONTROL...	60-01	EVAPORATOR	80-01
ADVANCED CONTROL SYSTEM (AHC)	60-01	EVAPORATOR/HEATER UNIT	80-01
ADVANCED CONTROL SYSTEM		EXPANSION VALVE	80-01
(AHC) (W/PUSH BUTTON FLOAT)	60-01		
AIR CLEANER	70-01	FAN GEARBOX	10-01
AIR CLEANER SERVICE	10-01	FINAL DRIVE TRANSMISSION (CHAINCASE).....	10-01
AIR CONDITIONING SERVICE	80-01	FLYWHEEL AND HOUSING	70-01
AIR CONDITIONING SYSTEM FLOW	80-01	FRONT AUXILIARY HYD. COUPLER BLOCK	20-01
ALTERNATOR (55 AMP)	60-01	FUEL SYSTEM.....	10-01
ALTERNATOR (90 AMP)	60-01	FUEL TANK	50-01
BASIC TROUBLESHOOTING	80-01	GENERAL AIR CONDITIONING SERVICE	
BATTERY	60-01	GUIDELINES	80-01
BICS™ SYSTEM	60-01		
BOBCAT CONTROLLER	60-01	HEATER COIL	80-01
BOBCAT INTERLOCK		HEATER/AC FAN	80-01
CONTROL SYSTEM (BICS™)	60-01	HEATER VALVE	80-01
BOB-TACH.....	10-01, 50-01	HYDRAULIC CONNECTION SPECS	SPEC-01
BRAKE	40-01	HYDRAULIC CONTROL VALVE	
BRAKE (TWO-SPEED).....	40-01	(ADVANCED CONTROL SYSTEM) (ACS)	20-01
BUCKET POSITION VALVE	20-01	HYDRAULIC CONTROL VALVE	
		(FOOT CONTROL).....	20-01
CHAINCASE	40-01	HYDRAULIC FLUID RESERVOIR	20-01
CHARGE PRESSURE	30-01	HYDRAULIC/HYDROSTATIC FILTER	20-01
COOLING FAN	70-01	HYDRAULIC FLUID SPECIFICATIONS.....	SPEC-01
COMPONENTS	80-01	HYDRAULIC/HYDROSTATIC SYSTEM.....	10-01
COMPRESSOR	80-01	HYDRAULIC PUMP	20-01
CONDENSER	80-01	HYDRAULIC SYSTEM INFORMATION	20-01
CONTROL HANDLE (ADVANCED CONTROL SYSTEM)		HYDROSTATIC MOTOR	30-01
(ACS) ADVANCED HAND CONTROL	20-01	HYDROSTATIC MOTOR (TWO-SPEED).....	30-01
CONTROL HANDLE (ADVANCED HAND CONTROL)		HYDROSTATIC PUMP	30-01
(AHC)	20-01	HYDROSTATIC SYSTEM INFORMATION.....	30-01
CONTROL HANDLE (ADVANCED HAND CONTROL)			
(AHC) (W/PUSH BUTTON FLOAT)	20-01	INSTRUMENT PANEL	60-01
CONTROL HANDLE (ADVANCED CONTROL SYSTEM)			
(ACS) SELECTABLE HAND/FOOT CONTROL...	20-01	LIFT ARMS	50-01
CONTROL PANEL	50-01	LIFT ARM BY-PASS VALVE	20-01
CONTROL PEDALS	50-01	LIFT ARM SUPPORT DEVICE.....	10-01
CONTROL PEDALS (ACS)	50-01	LIFTING AND BLOCKING THE LOADER.....	10-01
CONVERSIONS	SPEC-01	LIGHTS.....	60-01
CYLINDER (LIFT).....	20-01	LOADER SPECIFICATIONS	SPEC-01
CYLINDER (POWER BOB-TACH).....	20-01	LOADER TORQUE.....	SPEC-01
CYLINDER (TILT)	20-01	LUBRICATING THE LOADER.....	10-01
DELUXE INSTRUMENTATION SERVICE CODES	60-01	MAIN RELIEF VALVE (FOOT CONTROL)	20-01
DRIVE BELT	30-01	MUFFLER.....	70-01
DRIVE COMPONENTS	40-01		
ELECTRICAL/HYD. CONTROLS REFERENCE	60-01		
ELECTRICAL SYSTEM INFORMATION	60-01		
ENGINE & ENGINE MOUNTS	70-01		
ENGINE COMPONENTS AND TESTS	70-01		
ENGINE COOLING SYSTEM.....	10-01		



Thank you very much
for your reading.
Please click here
to get more information.