



Service Manual

236D SKID STEER LOADER

BGZ00001-UP



Printed in U.S.A

SENR5664-27 Air Conditioning and Heating R134a for All Caterpillar Machines _____	2
UENR3262-00 Seal Installation _____	33
UENR3278-07 C3.3B Tier 4 Final and EU Stage 3B Engines for Caterpillar Built Machines _____	96
UENR3728-01 259D, 279D and 289D Compact Track Loaders, 257D, 277D and 287D Multi Terrain Loaders _____	272
UENR3730-07 259D, 279D, 289D, 299D and 299D XHP Compact Track Loaders, 257D, 277D _____	345
UENR3731-04 259D, 279D, 289D, 299D and 299D XHP Compact Track Loaders, 257D, 277D _____	487

Air Conditioner Lines - Remove and Install _____	2
General Information _____	7
In-Line Refrigerant Dryer - Remove and Install _____	10
Machine Preparation for Disassembly and Assembly _____	18
Refrigerant Accumulator - Remove and Install _____	21
Refrigerant Compressor - Remove and Install _____	22
Refrigerant Expansion Valve - Remove and Install _____	24
Refrigerant Orifice Tube Assembly - Remove and Install _____	26
Refrigerant Receiver-Dryer - Remove and Install _____	30

[Previous Screen](#)

Product: SKID STEER LOADER

Model: 236D SKID STEER LOADER BGZ

Configuration: 236D Skid Steer Loader BGZ00001-UP (MACHINE) POWERED BY C3.3B Engine

Disassembly and Assembly

Air Conditioning and Heating R134a for All Caterpillar Machines

Media Number -SEN5664-27

Publication Date -01/05/2015

Date Updated -27/05/2015

105907621

Air Conditioner Lines - Remove and Install

SMCS - 1808-010



WARNING

Personal injury can result from contact with refrigerant.

This system is under pressure at all times, even if the engine is not running. Heat should never be applied to a charged system.

Contact with refrigerant can cause frost bite. Keep face and hands away to help prevent injury.

Protective goggles must always be worn when refrigerant lines are opened, even if the gauges indicate the system is empty of refrigerant.

Always use caution when a fitting is removed. Slowly loosen the fitting. If the system is still under pressure, evacuate the system recovering the refrigerant before removing the fitting.

Personal injury or death can result from inhaling refrigerant through a lit cigarette.

Inhaling air conditioner refrigerant gas through a lit cigarette or other smoking method or inhaling fumes released from a flame contacting air conditioner refrigerant gas, can cause bodily harm or death.

Do not smoke when servicing air conditioners or wherever refrigerant gas may be present.

Before any checks of the air conditioning and heating system are made, move the machine to a smooth horizontal surface. Lower all implements to the ground. Make sure the transmission is in neutral or park and that the parking brake is engaged. Keep all other personnel away from the machine or where they can be seen.



WARNING

Personal injury can result from hot coolant. Any contact with hot coolant or with steam can cause severe burns. Allow cooling system components to cool before the cooling system is drained.

NOTICE

Never weld or solder any charged components.

Care must be taken during removal of air conditioner lines. Before disconnecting any tube fittings, refer to Testing and Adjusting, "Refrigerant Recovery" in order to recover all refrigerant from the system.

Place dust caps on all hoses and fittings upon disconnecting.

Do not fold or twist hoses when you are routing the new hoses onto the machine. Damage can occur to the inner layers of the hoses and damage can cause premature failure.

Reassemble fittings by using the correct torque values for assembly of the air conditioning unit. Refer to Specifications, SENR3130, "Torque Specifications" in order to find the correct torque value.

Use the following procedure to reassemble the connections.

Proper Technique for Assembly



Thank you very much
for your reading.
Please click here
to get more information.