

JOHN DEERE 7610 AND 7620 KNUCKLEBOOM LOADERS




TECHNICAL MANUAL JOHN DEERE 7610 AND 7620 KNUCKLEBOOM LOADERS

TM1146 (01SEP75) English



TM1146 (01SEP75)

LITHO IN THE U.S.A.
ENGLISH



7610 AND 7620 KNUCKLEBOOM LOADERS

Technical Manual
TM-1146 (Sep-75)

CONTENTS

SECTION 10-GENERAL

- Group 5 Specifications
- Group 10 Lubrication
- Group 15 Loader Installation and Separation

SECTION 20-ENGINE

- Group 5 Diagnosing Malfunctions
- Group 10 Separation and Installation
- Group 15 Basic Engine
- Group 20 Engine Lubrication
- Group 25 Speed Control Linkage
- Group 30 Engine Cooling System
- Group 35 Specifications and Special Tools

SECTION 30-FUEL SYSTEM

- Group 5 Diagnosing Malfunctions
- Group 10 Fuel Tank, Fuel Filter and Fuel Transfer Pump
- Group 15 Fuel Injection Pump
- Group 20 Specifications

SECTION 40-ELECTRICAL SYSTEM

- Group 5 Wiring Diagrams
- Group 10 Charging System
- Group 15 Starting Motor
- Group 20 Specifications

SECTION 50-HYDRAULIC SYSTEM

- Group 5 Malfunction Diagnosis
- Group 10 Hydraulic Pump
- Group 15 Reservoir and Filters
- Group 20 Main Valve
- Group 25 Stabilizer Valve
- Group 30 Control Levers Linkage
- Group 35 Hydraulic Cylinders
- Group 40 Grapple Inline Crossover Relief Valve
- Group 45 Grapple Orbit Motor
- Group 50 Grapple High Torque Orbit Motor
- Group 55 Specifications


The specifications and design information contained in this manual were correct at the time it was printed. It is John Deere's policy to continually improve and update our machines. Therefore, the specifications and design information are subject to change without notice. Wherever applicable, specifications and design information are in accordance with SAE and IEMC standards.

SI (International System)
Units of Measure


Metric equivalents have been included, where applicable, throughout this technical manual.

Copyright© 1975
DEERE & COMPANY
Moline, Illinois
All rights reserved

INTRODUCTION



Use FOS Manuals for Reference



Use Technical Manuals for Actual Service

This technical manual is part of a twin concept of service:

- **FOS Manuals—for reference**
- **Technical Manuals—for actual service**

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

Fundamentals of Service (FOS) Manuals cover *basic* theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failures and their causes. FOS Manuals are for training new men and for reference by experienced men.

Technical Manuals are *concise* on-the-job service guides containing only the vital information needed for a specific machine.

Some features of this technical manual:

- *Table of contents at front of manual*
- *Exploded views showing parts relationship*
- *Photos showing service techniques*
- *Specifications grouped for easy reference*

This technical manual was planned and written for you—a journeyman mechanic. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.


Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.



This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.


SAFETY AND YOU

INTRODUCTION

 This safety alert symbol identifies important safety messages in this manual and on the knuckleboom loader. When you see this symbol, be alert to the possibility of bodily injury and carefully read the message that follows.



T27999N



T27504H

Be prepared if an accident or fire should occur. Know where the first aid kit and the fire extinguishers are located—know how to use them.



Thank you very much
for your reading.
Please click here
to get more information.