

2032R, 2036R and 2038R Compact Utility Tractors Diagnostic and Repair Manual

TECHNICAL MANUAL

2032R, 2036R and 2038R Compact Utility Tractors Diagnostic and Repair Manual

TM143919 20DEC20 (ENGLISH)

Engine Components
Service ADVISOR™ Manual
Information.....

information also see:

PDF  **DOWNLOAD** 

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the

beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX, TMIFC -19-13MAY13-1/1

Contents

Section 10—General Information

- Group 05A—Safety
- Group 05B—General References
- Group 05C—Technical Specific References
- Group 05D—Fuel and Lubricants
- Group 05E—Serial Number Locations

Section 20—Engine Repair

- Group 05—Engine
- Group 10—Cooling System

Section 30—Fuel, Air Intake, and Exhaust Repair

- Group 05—Fuel
- Group 10—Air Intake
- Group 15—Exhaust

Section 40—Electrical Repair

- Group 05—Electrical Connector Repair
- Group 10—Battery, Starter, and Alternator
- Group 15—Electrical System Components

Section 50—Drive Systems and Transmission Repair

- Group 05—Power Train
- Group 10—Mechanical Front Wheel Drive
- Group 15—Differential
- Group 20—PTO

Section 60—Steering Repair

- Group 05—Steering

Section 61—Brake Repair

- Group 05—Brake

Section 70—Hydraulics Repair

- Group 05—Hydraulic Pump and Filter
- Group 10—Rockshaft
- Group 15—Range Control and Three Point Hitch
- Group 20—Selective Control Valve
- Group 25—Hydraulic Lines

Section 80—Miscellaneous Repair

- Group 05—Hood and Side Panels
- Group 10—Fenders
- Group 15—Wheels

Section 90—Cab/Open Operator's Station Repair

- Group 05—Seat and Support
- Group 10—Control Console
- Group 15—Roll-Gard
- Group 25—Open Operator Station Components

Section 211—Diagnostic Trouble Codes

- Group 05—General References
- Group ECU—Engine Control Unit (ECU) Diagnostic Trouble Codes
- Group ICC—Instrument Cluster Control (ICC) Diagnostic Trouble Codes
- Group HOC—Height of Cut (HOC) Diagnostic Trouble Codes
- Group EIC—Engine Interface Control Unit (EIC) Diagnostic Trouble Codes

Section 212—Observable Symptoms and System Diagnostics

- Group 05—General References
- Group 20—Engine System Diagnostics
- Group 30—Fuel, Air Intake, Exhaust, and Cooling System Diagnostics
- Group 40—Electrical System Diagnostics
- Group 45—Electronic Control Unit System Diagnostics
- Group 50—Drive Systems and Transmission System Diagnostics
- Group 60—Steering System Diagnostics
- Group 61—Brakes System Diagnostics
- Group 70—Hydraulic System Diagnostics

Section 220—Engine Operation, Test, and Adjustments

- Group 05—General References
- Group 10—Calibrations, Preliminary Checks and Operational Checks
- Group 20—Theory of Operation
- Group 50—Tests and Adjustments

Section 230—Fuel, Air Intake, Exhaust, and Cooling Operation, Test, and Adjustments

- Group 05—General References
- Group 10—Calibrations, Preliminary Checks and Operational Checks
- Group 20—Theory of Operation

Continued on next page

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2020
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright © 2014, 2015, 2016, 2019

Group 40—Component and Connector Information
 Group 50—Tests and Adjustments

Section 240A—Electrical General and Theory of Operation

Group 05—General References
 Group 20—Electrical Theory of Operation

Section 240B—Electrical Schematics

Group 05—General References
 Group 30AA—Starting and Charging—With ECU (SE1A)
 Group 30AB—Starting and Charging—Without ECU (SE1B)
 Group 30BA—Lighting—Without License Light (SE2A)
 Group 30BB—Lighting—With License Light (SE2B)
 Group 30BC—Brake Switch, Horn, And Rear Trailer Connector (SE2C)
 Group 30CA—Instrument Cluster Control (ICC) (SE3)
 Group 30DA—Engine Control Unit (ECU) (SE4)
 Group 30EA—Vehicle Control Unit (VCU) (SE6)
 Group 30FA—Right Hand Fender (SE7)
 Group 30GA—Mauser Cab—With License Light (SE8)
 Group 30HA—Third EH SCV (SE9)

Section 240C—Electrical Components and Connectors

Group 05—General References
 Group 40A—Electrical Assemblies, Modules, and Control Units
 Group 40B—Sensors
 Group 40C—Resistors/Condensers/Capacitors
 Group 40D—Memory and Binary Devices
 Group 40E—Lights
 Group 40F—Fuses
 Group 40G—Charging
 Group 40H—Monitoring/Warning Devices
 Group 40K—Relays
 Group 40M—Motors
 Group 40S—Switches
 Group 40V—Diodes
 Group 40W—Wiring Harnesses
 Group 40X—Interconnects
 Group 40Y—Solenoids and Electrically Actuated Mechanical Devices
 Group 40Z—Ground Points

Section 240D—Electrical Tests and Adjustments

Group 05—General References
 Group 50—Tests and Adjustments

Section 245—Electronic Control Units

Group 05—General References
 Group 10—Calibrations, Preliminary Checks and Operational Checks
 Group 20—Theory of Operation
 Group 40—Component and Connector Information
 Group 50—Test and Adjustments
 Group ICC—Instrument Cluster Control (ICC)
 Group ECU—Engine Control Unit (ECU)

Group VCU—Height of Cut Control Unit (HOC)
 Group EIC—Engine Interface Control Unit (EIC)

Section 250—Drive Systems and Transmission Operation, Test, and Adjustments

Group 05—General References
 Group 10—Calibrations, Preliminary Checks and Operational Checks
 Group 20—Theory of Operation
 Group 30—Schematics
 Group 40—Component and Connector Information
 Group 50—Tests and Adjustments

Section 260—Steering Operation, Test, and Adjustments

Group 05—General References
 Group 10—Calibrations, Preliminary Checks and Operational Checks
 Group 20—Theory of Operation
 Group 30—Schematics
 Group 40—Component and Connector Information
 Group 50—Tests and Adjustments

Section 261—Brakes Operation, Test, and Adjustments

Group 05—General References
 Group 10—Calibrations, Preliminary Checks and Operational Checks
 Group 20—Theory of Operation
 Group 40—Component and Connector Information
 Group 50—Tests and Adjustments

Section 270—Hydraulics Operation, Test, and Adjustments

Group 05—General References
 Group 10—Calibrations, Preliminary Checks and Operational Checks
 Group 20—Theory of Operation
 Group 30—Schematics
 Group 40—Component and Connector Information
 Group 50—Tests and Adjustments

Section 290—Cab/Open Operators Station Operation, Test, and Adjustments

Group 05—General References
 Group 20—Theory of Operation
 Group 30—Schematics
 Group 40—Component and Connector Information

Section 299—Service Tools

Group 05A—General References
 Group 05C—Dealer Fabricated and Service Tools

Section 10 General Information

Contents

	Page		Page
Group 05A—Safety			
Work In Ventilated Area	10-05A-1		
Recognize Safety Information	10-05A-1		
Avoid Backover Accidents	10-05A-1		
Prevent Machine Runaway	10-05A-2		
Avoid Contact with Agricultural Chemicals	10-05A-2		
Clean Vehicle of Hazardous Pesticides	10-05A-2		
Use a Safety Chain	10-05A-3		
Work in Clean Area	10-05A-3		
Decommissioning — Proper Recycling and Disposal of Fluids and Components	10-05A-4		
Avoid Harmful Asbestos Dust	10-05A-4		
Avoid Hot Exhaust	10-05A-5		
Clean Exhaust Filter Safely	10-05A-6		
Handle Fuel Safely—Avoid Fires	10-05A-7		
Prepare for Emergencies	10-05A-7		
Handle Fluids Safely—Avoid Fires	10-05A-7		
Avoid High-Pressure Fluids	10-05A-8		
Install All Guards	10-05A-8		
Use Proper Lifting Equipment	10-05A-8		
Illuminate Work Area Safely	10-05A-9		
Live With Safety	10-05A-9		
Service Machines Safely	10-05A-9		
Support Machine Properly	10-05A-10		
Remove Paint Before Welding or Heating	10-05A-10		
Park Machine Safely	10-05A-10		
Stay Clear of Rotating Drivelines	10-05A-11		
Follow Safety Instructions	10-05A-12		
Use Proper Tools	10-05A-12		
Service Tires Safely	10-05A-13		
Keep ROPS Installed Properly	10-05A-13		
Construct Dealer-Made Tools Safely	10-05A-14		
Practice Safe Maintenance	10-05A-14		
Understand Signal Words	10-05A-15		
Replace Safety Signs	10-05A-15		
Avoid Heating Near Pressurized Fluid Lines	10-05A-15		
Wear Protective Clothing	10-05A-16		
Service Accumulator Systems Safely	10-05A-16		
Handling Batteries Safely	10-05A-17		
Handle Agricultural Chemicals Safely	10-05A-18		
Service Cooling System Safely	10-05A-18		
Use Steps and Handholds Correctly	10-05A-19		
Transport Tractor Safely	10-05A-19		
		Group 05B—General References	
		Deliver Safely	10-05B-1
		Information Available in Sections, Groups and Subgroups	10-05B-2
		Glossary of Terms	10-05B-3
		Trademarks	10-05B-5
		Group 05C—Technical Specific References	
		Unified Inch Bolt and Screw Torque Values	10-05C-1
		Metric Bolt and Screw Torque Values	10-05C-2
		Metric Cap Screw Torque Values—Grade 7	10-05C-3
		Gasket Sealant Application	10-05C-3
		Service Recommendations for O-Ring Boss Fittings	10-05C-3
		Service Recommendations for Flat Face O-Ring Seal Fittings	10-05C-5
		Group 05D—Fuel and Lubricants	
		Diesel Fuel	10-05D-1
		Handling and Storing Diesel Fuel	10-05D-2
		Engine Oil	10-05D-2
		Alternative and Synthetic Lubricants	10-05D-3
		Lubricant Storage	10-05D-3
		Mixing of Lubricants	10-05D-3
		Multipurpose Extreme Pressure (EP) Grease	10-05D-4
		Transmission and Hydraulic Oil	10-05D-5
		Diesel Engine Coolant	10-05D-6
		Group 05E—Serial Number Locations	
		Serial Numbers	10-05E-1
		Machine Product Identification Number	10-05E-1
		Engine Serial Number	10-05E-1
		Transmission Serial Number	10-05E-1



Thank you very much
for your reading.
Please click here
to get more information.