

# 540E, 640E, 740E Skidder; 548E, 648E, 748E Grapple Skidder



JOHN HARE



COLLECTION

## REPAIR TECHNICAL MANUAL

**Cable models 540E, 640E, 740E; Grapple models 548E, 648E, 748E**

**TM1486 14 APR 05 (ENGLISH)**

**For complete service information also see:**

540E, 640E and 740E Skidder; 548E,648E and 748E Grapple Skidder Diagnostic	TM1485
Series 300, 3029, 4039, 4045, 6059 and 6068 Diesel Engines	CTM8
Alternators and Starting Motors	CTM77
Series 400, 6076 Diesel Engines ( - 499999)	CTM6
TeamMate II 1200, 1400, and 1600 Series Inboard Planetary Axles	CTM43
Series 400, 6076 Diesel Engines	
60 and 6000 Winches	
40 and 4000 Winches	
TeamMate II 1200, 1400, 1600 and 1800 Series Inboard Planetary Axles	CTM18



## Table of contents

### **FOREWORD**

### **HELP!! HELP!! HELP!! HELP!!**

### **Section 00 - GENERAL INFORMATION**

- Group 0001 - Safety
- Group 0002 - General Specifications
- Group 0003 - Torque Value
- Group 0004 - Fuels And Lubricants

### **Section 01 - WHEELS**

- Group 0110 - Powered Wheels And Fastenings

### **Section 02 - AXLES AND SUSPENSION SYSTEM**

- Group 0200 - Removal And Installation
- Group 0225 - Input Drive Shafts And U-Joints
- Group 0260 - Hydraulic System

### **Section 03 - TRANSMISSION**

- Group 0300 - Removal And Installation
- Group 0315 - Control Linkage
- Group 0325 - Input Drive Shafts And U-Joints
- Group 0350 - Gears, Shafts And Bearings
- Group 0360 - Hydraulic System

### **Section 04 - ENGINE**

- Group 0400 - Removal And Installation

### **Section 05 - ENGINE AUXILIARY SYSTEMS**

- Group 0505 - Cold Weather Starting Aids
- Group 0510 - Cooling Systems
- Group 0515 - Speed Controls
- Group 0520 - Intake System
- Group 0530 - External Exhaust System
- Group 0560 - External Fuel Supply System

### **Section 07 - DAMPER DRIVE**

- Group 0752 - Elements

### **Section 09 - STEERING SYSTEM**

- Group 0930 - Secondary Steering
- Group 0960 - Hydraulic System

### **Section 10 - SERVICE BRAKES**

- Group 1011 - Active Elements
- Group 1015 - Controls Linkage
- Group 1060 - Hydraulic System

### **Section 11 - PARK BRAKE**

- Group 1111 - Active Elements
- Group 1160 - Hydraulic System

### **Section 16 - ELECTRICAL SYSTEM**

- Group 1671 - Batteries, Support And Cables
- Group 1672 - Alternator, Regulator And Charging System Wiring
- Group 1673 - Lighting System
- Group 1674 - Wiring Harness And Switches
- Group 1676 - Instruments And Indicators
- Group 1677 - Motors And Actuators

### **Section 17 - FRAME, CHASSIS, OR SUPPORTING STRUCTURES**

- Group 1740 - Frame Installation
- Group 1746 - Frame Bottom Guards

### **Section 18 - OPERATOR'S STATION**

- Group 1800 - Removal And Installation

- Group 1810 - Operator Enclosure
- Group 1821 - Seat And Seat Belt
- Group 1830 - Heating And Air Conditioning

**Section 19 - SHEET METAL AND STYLING**

- Group 1910 - Hood Or Engine Enclosure
- Group 1921 - Grille And Grille Housing

**Section 20 - SAFETY, CONVENIENCE AND MISCELLANEOUS**

- Group 2004 - Horn And Warning Devices

**Section 21 - MAIN HYDRAULIC SYSTEM**

- Group 2160 - Hydraulic System

**Section 30 - WINCH**

- Group 3000 - Removal And Installation
- Group 3015 - Controls Linkage
- Group 3025 - Input Drive Shafts And U-Joints
- Group 3050 - Drive And Clutch

**Section 32 - BULLDOZERS (STACKING AND TRAILBUILDING BLADES)**

- Group 3201 - Blades
- Group 3215 - Controls Linkage
- Group 3260 - Hydraulic System

**Section 37 - ARCH OR BOOM**

- Group 3740 - Frames

**Section 38 - GRAPPLE**

- Group 3803 - Grapple Mechanism
- Group 3815 - Controls Linkage
- Group 3840 - Frames
- Group 3860 - Hydraulic System

**Section 99 - DEALER FABRICATED TOOLS**

- Group 9900 - Dealer Fabricated Tools



## Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



**CAUTION:**



***This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.***

---

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.



Thank you very much  
for your reading.  
Please click here  
to get more information.