

326D, 328D, 329D, 332D and 333D Skid Steer Loader Repair (Manual Controls)

TECHNICAL MANUAL 326D, 328D, 329D, 332D and 333D Skid Steer Loader Repair (Manual Controls)

TM11431 15FEB13 (ENGLISH)

For complete service information also see:

326D, 328D and 332D Skid Steer Loader Operation and Test (Manual Controls)	TM11430
329D and 333D Skid Steer Loader Operation and Test (Manual Controls)	TM11446
326D, 328D and 332D Skid Steer Loader Operation and Test (EH Controls)	TM11431
329D and 333D Skid Steer Loader Oper and Test (EH Controls)	TM11446
326D, 328D, 329D, 332D and 333D Skid Steer Loader Repair (EH Controls)	TM11431
326D, 328D and 332D Skid Steer Loader Operator's Manual	OMT253018
329D and 333D Skid Steer Loader Operator's Manual	OMT253017
PowerTech E™ 2.4L and 3.0L Diesel Engines Component Technical Manual	CTM101019
120 Series Hydraulic Cylinders	CTM114319
Specifications Manual	SP458VOL2




**Worldwide Construction
And Forestry Division**
LITHO IN U.S.A.

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

MM16284,0001A38 -19-01FEB13-1/1

Contents

Section 00—General Information

- Group 0001—Safety
- Group 0003—Torque Values

- Group 3140—Frame
- Group 3160—Hydraulic System

Section 01—Wheels or Tracks

- Group 0110—Powered Wheels and Fastenings
- Group 0130—Track System

Section 99—Dealer Fabricated Tools

- Group 9900—Dealer Fabricated Tools

Section 02—Axles and Suspension Systems

- Group 0201—Drive Axle Housing and Support
- Group 0250—Axle Shaft, Bearings, and Reduction Gears

Section 03—Transmission

- Group 0315—Controls Linkage
- Group 0325—Flywheel Coupler
- Group 0360—Hydraulic System

Section 04—Engine

- Group 0400—Removal and Installation

Section 05—Engine Auxiliary System

- Group 0510—Cooling Systems
- Group 0520—Intake System
- Group 0530—External Exhaust Systems
- Group 0560—External Fuel Supply Systems

Section 17—Frame or Supporting Structure

- Group 1740—Frame Installation

Section 18—Operator's Station

- Group 1800—Removal and Installation
- Group 1810—Operator Enclosure
- Group 1821—Seat and Seat Belt
- Group 1830—Heating and Air Conditioning

Section 19—Sheet Metal and Styling

- Group 1910—Hood or Engine Enclosure

Section 20—Safety and Convenience

- Group 2001—Radio

Section 21—Main Hydraulic System

- Group 2160—Hydraulic System

Section 31—Loader

- Group 3104—Attachment Coupler
- Group 3115—Control Linkage

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2013
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION © Manual
Previous Editions
Copyright © 2010, 2011, 2012

Contents

Section 00 General Information

Contents

	Page		Page
Group 0001—Safety			
Recognize Safety Information	00-0001-1	Service Recommendations for 37° Flare and 30° Cone Seat Connectors	00-0003-6
Follow Safety Instructions.....	00-0001-1	Service Recommendations For Flared Connections—Straight or Tapered Threads	00-0003-7
Operate Only If Qualified	00-0001-1	Inch Series Four Bolt Flange Fitting For High Pressure Service Recommendations.....	00-0003-8
Wear Protective Clothing.....	00-0001-2	Service Recommendations For Inch Series Four Bolt Flange Fittings.....	00-0003-9
Avoid Unauthorized Machine Modifications.....	00-0001-2	Service Recommendation O-Ring Face Seal Fittings with SAE Inch Hex Nut and Stud End for High Pressure.....	00-0003-10
Inspect Machine	00-0001-2	O-Ring Face Seal Fittings with Metric Hex Nut and Stud End for Standard Pressure.....	00-0003-12
Stay Clear of Moving Parts.....	00-0001-2	O-Ring Face Seal Fittings with Metric Hex Nut and Stud End for High Pressure.....	00-0003-14
Avoid High-Pressure Fluids	00-0001-3	Service Recommendations for Metric Series Four Bolt Flange Fitting.....	00-0003-16
Avoid High-Pressure Oils	00-0001-3		
Work In Ventilated Area.....	00-0001-4		
Prevent Fires	00-0001-4		
Prevent Battery Explosions	00-0001-5		
Handle Chemical Products Safely.....	00-0001-5		
Dispose of Waste Properly	00-0001-5		
Prepare for Emergencies.....	00-0001-6		
Clean Debris from Machine.....	00-0001-6		
Use Steps and Handholds Correctly	00-0001-6		
Start Only From Operator's Seat.....	00-0001-6		
Use and Maintain Seat Belt.....	00-0001-7		
Prevent Unintended Machine Movement.....	00-0001-7		
Avoid Work Site Hazards.....	00-0001-8		
Keep Riders Off Machine	00-0001-8		
Avoid Backover Accidents	00-0001-8		
Avoid Machine Tip Over	00-0001-9		
Operating On Slopes	00-0001-9		
Operating Or Traveling On Public Roads	00-0001-9		
Inspect and Maintain ROPS	00-0001-10		
Add and Operate Attachments Safely.....	00-0001-10		
Park and Prepare for Service Safely.....	00-0001-10		
Service Cooling System Safely	00-0001-11		
Remove Paint Before Welding or Heating	00-0001-11		
Make Welding Repairs Safely	00-0001-11		
Drive Metal Pins Safely	00-0001-12		
Service Tires Safely.....	00-0001-12		
Handle Cab Door Safely.....	00-0001-12		
Group 0003—Torque Values			
Unified Inch Bolt and Screw Torque Values.....	00-0003-1		
Metric Bolt and Screw Torque Values.....	00-0003-2		
Additional Metric Cap Screw Torque Values	00-0003-3		
Check Oil Lines And Fittings	00-0003-4		
Service Recommendations for O-Ring Boss Fittings.....	00-0003-4		



Thank you very much
for your reading.
Please click here
to get more information.