

XUV865E, XUV865M and XUV865R Gator™ Utility Vehicles (SN. 010001-)



JOHN HARE



COLLECTION

TECHNICAL MANUAL

XUV865E, XUV865M and XUV865R Gator™ Utility Vehicles (SN. 010001-)

TM145619 01DEC18 (ENGLISH)



Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



CAUTION:

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components.

Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX,TMIFC-19-20140415

Section 10 - General Information

[Group 10 - Safety](#)
[Group 20 - General Specifications](#)
[Group 30 - Fuel and Lubricants](#)
[Group 40 - Machine Specifications](#)

Section 20 - Engine Repair

[Group 10 - Engine](#)

Section 30 - Electrical Repair

[Group 10 - Wiring Harnesses](#)

Section 40 - Power Train Repair

[Group 10 - Transmission](#)
[Group 20 - Axles and Driveshaft](#)
[Group 30 - Mechanical Front Wheel Drive](#)

Section 50 - Steering and Brake Repair

[Group 10 - Steering](#)
[Group 20 - Brakes](#)

Section 60 - Operator`s Station Repair

[Group 10 - Operator`s Station](#)

Section 70 - Miscellaneous Repair

[Group 10 - Wheels](#)
[Group 20 - Hood, Cargo Box, and Bumper](#)
[Group 30 - Miscellaneous Repair](#)

Section 220 - Engine Operation, Tests, and Adjustments

[Group 10 - Component Location](#)
[Group 20 - Theory of Operation](#)
[Group 30 - Diagnosis](#)
[Group 40 - Tests and Adjustments](#)

Section 230 - Electrical Operation, Tests, and Adjustments

[Group 10 - General Information](#)
[Group 20 - Component Location](#)
[Group 30 - Theory of Operation](#)
[Group 40 - Schematics](#)
[Group 50 - Schematics, Kits](#)
[Group 60 - Connector Information](#)
[Group 70 - Tests and Adjustments](#)

Section 240 - Control Unit Operation, Tests and Adjustments

[Group 10 - Theory of Operation](#)
[Group 20 - Diagnostic Trouble Codes, ICC](#)
[Group 30 - Diagnostic Trouble Codes, SCU](#)
[Group 40 - Service ADVISOR Readings](#)

Section 250 - Power Train Operation, Tests, and Adjustments

[Group 10 - Component Location](#)
[Group 20 - Theory of Operation](#)
[Group 30 - Diagnosis](#)
[Group 40 - Tests and Adjustments](#)

Section 260 - Steering and Brake Operation, Tests, and Adjustments

[Group 10 - Component Location](#)
[Group 20 - Theory of Operation](#)
[Group 30 - Diagnosis](#)
[Group 40 - Tests and Adjustments](#)

Section 299 - Service Tools

[Group 10 - Service Tools and Kits](#)

Section 10

General Information

Contents

	Page		Page
Group 10 - Safety		Service Recommendations For Flat Face O - Ring Seal Fittings	10-20-2
Recognize Safety Information	10-10-1	Metric Cap Screw Torque Values - Grade 7	10-20-2
Understand Signal Words	10-10-1	Metric Bolt and Screw Torque Values	10-20-3
Practice Safe Maintenance	10-10-2	Unified Inch Bolt and Screw Torque Values	10-20-4
Use Proper Tools	10-10-2	Group 30 - Fuel and Lubricants	
Handle Fluids Safely - Avoid Fires	10-10-2	Diesel Fuel - North America	10-30-1
Prevent Acid Burns	10-10-3	Diesel Fuel - Europe	10-30-1
Prevent Battery Explosions	10-10-3	Diesel Fuel Storage	10-30-2
Handling Batteries Safely	10-10-3	4 - Cycle Diesel Engine Oil - North America	10-30-2
Prepare for Emergencies	10-10-4	Diesel Engine Oil - Europe	10-30-2
Park Machine Safely	10-10-4	Oil Filters	10-30-3
Support Machine Properly	10-10-5	Transmission and Hydraulic Oil	10-30-3
Wear Protective Clothing	10-10-5	Grease	10-30-3
Work in Clean Area	10-10-5	Mixing of Lubricants	10-30-3
Service Machines Safely	10-10-5	Alternative and Synthetic Lubricants	10-30-4
Work In Ventilated Area	10-10-6	Lubricant Storage	10-30-4
Illuminate Work Area Safely	10-10-6	Operating in Warm Temperature Climates	10-30-4
Replace Safety Signs	10-10-6	Diesel Engine Coolant (engine without wet sleeve cylinder liners)	10-30-5
Use Proper Lifting Equipment	10-10-6	John Deere COOL - GARD™ II Coolant Extender	10-30-5
Follow Tire Recommendations	10-10-7	Testing Diesel Engine Coolant	10-30-6
Protect Against High Pressure Spray	10-10-7	Group 40 - Machine Specifications	
Decommissioning - Proper Recycling and Disposal of Fluids and Components	10-10-7	Machine Specifications	10-40-1
Live With Safety	10-10-8	Product Identification Number Location	10-40-1
Group 20 - General Specifications			
Service Recommendations for O - Ring Boss Fittings	10-20-1		



Thank you very much
for your reading.
Please click here
to get more information.