

4050, 4250 and 4450 Tractors



TECHNICAL MANUAL 4050, 4250 and 4450 Tractors

TM1353 (01SEP87) English



TM1353 (01SEP87)

LITHO IN U.S.A.
ENGLISH



4050, 4250 AND 4450 TRACTORS TECHNICAL MANUAL TM-1353 (SEP-87)

CONTENTS—REPAIR SECTIONS

PUBLICATION NUMBER CHANGE

This technical manual was formerly TM-1257. The number was changed to TM-1353 when engine information was removed. Some pages still carry the old publication number. For engine information, refer to engine component technical manual, CTM-1, 6466 Engines or to CTM-4, 6359 Engines. This machine technical manual covers removal and installation of the engine components. The component manual covers basic repair of the engine. For main hydraulic pump repair information, refer to component technical manual, CTM-7, Radial Piston Pumps.

SECTION 10—GENERAL

- Group 05—Predelivery, Delivery and After-Sale Services
- Group 10—Tune-up
- Group 15—Lubrication

SECTION 15—SEPARATION

- Group 05—Front Axle
- Group 10—Front-End
- Group 15—Front-End and Engine
- Group 20—Engine
- Group 25—SOUND-GARD® body and ROLL-GARD® Protective Structure
- Group 30—Power Shift Clutch Housing
- Group 31—QUAD-RANGE™ Clutch Housing
- Group 35—Transmission
- Group 40—Final Drives
- Group 41—Hi-Crop Final Drives

SECTION 20—ENGINE

- Group 05—Acquire Access to Cylinder Head, Valves and Camshaft
- Group 10—Acquire Access to Cylinder Block, Liners, Pistons and Rods
- Group 15—Acquire Access to Crankshaft, Main Bearings and Flywheel
- Group 20—Acquire Access to Lubrication System
- Group 25—Remove/Install Cooling System

SECTION 30—FUEL AND AIR SYSTEM

- Group 05—Acquire Access to Air Intake System
- Group 10—Acquire Access to Diesel Fuel System
- Group 15—Speed Control Linkage

SECTION 40—ELECTRICAL

- Group 05—Harness Replacement
- Group 06—Connector Repair
- Group 10—Remove/Install Delco-Remy Charging Circuit
- Group 11—John Deere Charging Circuit Repair
- Group 15—Starting Circuit Replacement
- Group 25—Lighting Circuit Repair
- Group 30—INVESTIGATOR IITM Warning System and Digital Tachometer Repair
- Group 31—Gauge Cluster Instrumentation Repair
- Group 32—Analog Tachometer Repair
- Group 35—Accessories Circuit Repair

Continued on next page

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1987
DEERE & COMPANY
Moline, Illinois
All rights reserved
A JOHN DEERE ILLUSTRATION
Previous Edition Copyright© 1982, 1983, 1984, 1985, 1986
DEERE & COMPANY

U10;010GEN AX3 021087

CONTENTS—CONTINUED

SECTION 50—POWER TRAIN—PERMA CLUTCH™ TRANSMISSION

- Group 05—Remove/Install Clutch Oil Pressure Valve Housing
- Group 10—Clutch Oil Pressure Regulating Valve Housing
- Group 15—Clutch Operating Piston Housing
- Group 20—PERMA CLUTCH
- Group 30—4050 and 4250 QUAD-RANGE Planetary
- Group 31—4450 QUAD-RANGE Planetary
- Group 35—Eight-Speed Transmission & Charge Pump
- Group 45—Shift Lever Assembly
- Group 55—PTO Gear Train (without MFWD)
- Group 56—PTO Gear Train (with MFWD)
- Group 60—Adjust PTO Clutch Rod
- Group 65—4050 (Trans. Serial No. -006643) Differential
- Group 66—4050 (Trans. Serial No. 006644-), 4250 and 4450 Differential
- Group 70—Remove/Install Differential Lock Valve and Adjust Lock Valve Release Bar
- Group 75—Differential Lock Valve
- Group 80—Final Drive
- Group 85—Hi-Crop Final Drive
- Group 90—MFWD Gear Train and Clutch
- Group 95—MFWD Axle

SECTION 55—POWER TRAIN—POWER SHIFT TRANSMISSION

- Group 05—Remove/Install Traction Clutch Valve Housing
- Group 10—Traction Clutch Valve Housing
- Group 15—Remove/Install Transmission Control Valve Housing
- Group 20—Transmission Control Valves
- Group 25—Remove/Install Traction Clutch
- Group 30—Traction Clutch and Drive Shafts
- Group 35—Input Planetary
- Group 40—Reduction Gear Train
- Group 45—4050 and 4250 Output Planetary
- Group 46—4450 Output Planetary
- Group 50—Speed Selector Assembly
- Group 55—Charge Pump Assembly
- Group 60—PTO Gear Train with MFWD
- Group 61—PTO Gear Train without MFWD
- Group 65—Adjust PTO Clutch Rod

- Group 70—4050 (Trans. Serial No. -002724) Differential
- Group 71—4050 (Trans. Serial No. 002725-), 4250 and 4450 Differential
- Group 75—Remove/Install Differential Lock Valve and Adjust Lock Valve Release Bar
- Group 80—Differential Lock Valve
- Group 85—Final Drive
- Group 90—Hi-Crop Final Drive
- Group 95—MFWD Gear Train
- Group 100—MFWD Clutch
- Group 105—MFWD Axle and Final Drive

SECTION 60—STEERING/BRAKES

- Group 05—Remove/Install Power Steering Components
- Group 10—Steering Column
- Group 15—Metering Pump
- Group 20—Steering Valve
- Group 25—Steering Motor
- Group 26—Dual Piston Steering Motor
- Group 30—Steering Assist Cylinders (MFWD)
- Group 35—Remove/Install Brake Valve and Brake Accumulator
- Group 40—Brake Valve
- Group 45—Brake Accumulator
- Group 50—Bleeding Brakes and Testing Brake Accumulator
- Group 55—Brake Pistons, Plates and Disks

SECTION 70—HYDRAULICS

- Group 05—Remove/Install Main Hydraulic Pump
- Group 15—Oil Filter Relief Valve Housing (QRT)
- Group 20—Return Oil Filter Relief Valve Housing (PST)
- Group 25—Remove/Install Attenuator
- Group 30—Hydraulic Attenuator
- Group 35—Remove/Install HYDRACUSHIONED Seat Valve
- Group 40—Repair HYDRACUSHIONED Seat Valve Assembly
- Group 45—Pressure Control Valve
- Group 50—Remove/Install Rockshaft Components and Adjust Lift Assist Cylinders
- Group 55—Rockshaft Components
- Group 60—Lift Assist Cylinders

Continued on next page

CONTENTS—CONTINUED

SECTION 70—HYDRAULICS—Continued

- Group 65—Draft Sensing Components
- Group 70—Hitch Components
- Group 75—Remove/Install SCV Coupler & Levers
- Group 80—SCV and ISO Coupler
- Group 85—Remote Cylinder
- Group 90—Hydraulic Oil Cooler and Thermal Bypass Valve
- Group 95—Transmission-Hydraulic System Clean-up Procedure

SECTION 80—MISCELLANEOUS

- Group 05—Rear Wheels
- Group 10—Front Axle

SECTION 90—OPERATOR STATION

- Group 05—Air Conditioning System
- Group 06—Air Conditioning System Service
- Group 10—Heating System
- Group 15—Seat

SECTION 95—MISCELLANEOUS OPTIONS

- Group 40—Auxiliary Lighting and Electrical Components
- Group 45—Digital Tachometer Ground Speeds
- Group 62—Auxiliary Trailer Brake
- Group 63—Secondary Brake
- Group 80—Minor Options
- Group 85—Auxiliary Steering System

SECTION 99—SPECIAL TOOLS

INTRODUCTION

This manual is part of a total service support program.

FOS Manuals—reference


Technical Manuals—machine service

Component Manuals—component service

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise service guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand alone manuals covering multiple machine applications.



AB6;RW5559 053;INTR02 030785

FEATURES OF THIS TECHNICAL MANUAL

John Deere ILLUSTRATION format emphasizing illustrations and concise instructions in easy-to-use modules.

Emphasis on diagnosis, analysis, and testing so you can understand the problem and correct it.


Diagnostic information presented with the most logical and easiest to isolate problems first to help you identify the majority of routine failures quickly.

Step-by-step instructions for teardown and assembly.

Summary listing at the beginning of each group of all applicable specifications, wear tolerances, torque values, essential tools, and materials needed to do the job.

An emphasis throughout on safety—so you do the job right without getting hurt.

This technical manual was planned and written for you—an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it when you need to know correct service procedures or specifications.



AB6;RW5560 053;INTR03 071085



Thank you very much
for your reading.
Please click here
to get more information.