

# 9410, 9510 and 9610 Combines Diagnosis and Tests

For complete service information also see:

Cutting Platforms, Corn Heads Heads . . . . .	<b>PDF</b> 	<b>DOWNLOAD</b> 
GreenStar™ Yield Mapping Repair, and Test . . . . .		TM1685
GreenStar™ Yield Monitoring Repair, Operation and Test . . . . .		TM1686
9410, 9510, and 9610 Combines Repair . . . . .		TM1701
Cam Lobe Motors . . . . .		CTM19
Engine Accessories . . . . .		CTM67
Electronic Fuel Injection . . . . .		CTM68
Alternators and Starting Motors . . . . .		CTM77
6081 Diesel Engines . . . . .		CTM86
6068 Engine . . . . .		CTM104

**John Deere Harvester Works**  
**TM1702 (29AUG97)**

# Introduction

## Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX, TMIFC -19-22MAY92-1/1

# Contents

## SECTION 210—General

- Group 05—Safety
- Group 10—Combine or Component Identification
- Group 15—General Specifications
- Group 20—Diagnostic/Testing Procedures
- Group 25—Electrical System Operational Checkout

## SECTION 220—Engine Operation and Tests

- Group 10—Cooling System and Rotary Screen Operation
- Group 20—6081 Engine Operation—Bosch

## SECTION 230—Fuel/Air Operation and Tests

- Group 05—Air Intake System
- Group 10—Fuel System

## SECTION 240—Electrical System Operation and Tests

- Group 5A—Electrical Schematic Symbols
- Group 5B—How to Use This Diagnostic Information
- Group 5C—Service Equipment and Tools
- Group 5D—Seven Step Electrical Test Procedure
- Group 5E—Visually Inspect Electrical System
- Group 5F—Wiring Diagram and Schematic Information
- Group 10—Ground Points
- Group 15A—Air Suspension Seat Diagnostics
- Group 15B—Alternator and Battery Diagnostics
- Group 15C—Auxiliary Field Lights Diagnostics
- Group 15D—Auxiliary Power Outlet Diagnostics
- Group 15E—Backshaft Speed Adjust Diagnostics
- Group 15F—Combine Data Center Diagnostics
- Group 15G—Concave Position Adjust Diagnostics
- Group 15H—Contour Master™ (HDR Tilt) Control System Identification
- Group 15I—Contour Master™ (HDR Tilt) Control Diagnostics—Type A
- Group 15J—Contour Master™ (HDR Tilt) Control Diagnostics—Type B
- Group 15K—Corn Head Adjustable Deck Plates Diagnostics
- Group 15L—Corner Post Gauges Diagnostics
- Group 15M—Cylinder Speed Adjust Diagnostics
- Group 15N—DIAL-A-MATIC™ System Identification
- Group 15O—DIAL-A-MATIC™ Diagnostics—Type A
- Group 15P—DIAL-A-MATIC™ Diagnostics—Type B
- Group 15Q—DIAL-A-SPEED™ Diagnostics
- Group 15R—Dual Display Digital Tachometer Diagnostics
- Group 15S—Electric Fuel Pump Diagnostics
- Group 15T—Engine Compartment Relay Panel Diagnostics
- Group 15U—Engine Oil Pressure Monitor Diagnostics
- Group 15V—Fan Speed Adjust Diagnostics
- Group 15W—Four-Wheel Drive Diagnostics
- Group 15X—HarvesTrak™ Diagnostics
- Group 15Y—Header Engage Diagnostics
- Group 15Z—Header Raise/Lower Diagnostics
- Group 15AA—Header Raise/Lower Diagnostics With DIAL-A-MATIC™
- Group 15AB—Heating and Air Conditioning Diagnostics
- Group 15AC—Horn Diagnostics
- Group 15AD—Injection Pump (Engine Control) System Identification
- Group 15AE—Injection Pump System—6081 John Deere Type A—Diagnostics
- Group 15AF—Injection Pump System—6081 John Deere Type B—Diagnostics
- Group 15AG—Injection Pump System—6068 Engine—Diagnostics
- Group 15AH—Lighting System Diagnostics
- Group 15AI—Low Shaft Speed Monitor Diagnostics (w/o GreenStar™)
- Group 15AJ—Low Shaft Speed Monitor Diagnostics (with GreenStar™)
- Group 15AK—Parking Brake Diagnostics
- Group 15AL—Power Distribution Board Diagnostics
- Group 15AM—Radio System Diagnostics
- Group 15AN—Reel/Belt Speed Diagnostics
- Group 15AO—Reel Fore/Aft Diagnostics
- Group 15AP—Reel Raise/Lower Diagnostics
- Group 15AQ—Separator Engage Diagnostics
- Group 15AR—Shoe Lighting Diagnostics
- Group 15AS—Starting Aid Diagnostics
- Group 15AT—Starting System Diagnostics
- Group 15AU—Unloading Auger Engage Diagnostics

Continued on next page

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

COPYRIGHT © 1997  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A John Deere ILLUSTRATION® Manual

210

Group 15AV—Unloading Auger Swing System Identification

Group 15AW—Unloading Auger Swing Diagnostics—Type A

220

Group 15AX—Unloading Auger Swing Diagnostics—Type B

Group 15AY—Warning Display Panel Diagnostics

Group 15AZ—Wiper System Diagnostics

Group 20A—Circuit Code Listing

Group 20B—Connector Number Listing and End Views

230

**SECTION 250—Power Train Operation and Tests**

Group 00—Power Train Diagnostic Specifications

Group 05—Transmission and Final Drives

240

Group 10—Hydrostatic Drive System Adjustments

Group 15—Hydrostatic Drive System Operational Tests

Group 20—Hydraulic/Hydrostatic System Overheating Diagnostics

Group 25—Hydro Charge Pressure Low Diagnostics

250

Group 30—Hydrostatic Drive System Diagnostics

Group 32—Transmission Lubrication Pump Diagnostics

Group 35—Hydrostatic Drive System Theory of Operation

255

**SECTION 255—Four-Wheel Drive**

Group 00—Four-Wheel Drive

Group 05—Four-Wheel Drive System Operational Checks

Group 10—Four-Wheel Drive Diagnostics

260

Group 15—Four-Wheel Drive System Theory of Operation

**SECTION 260—Service Brakes System Operation and Tests**

Group 00—Service Brake System Specifications and Adjustments

Group 05—Service Brake System Diagnostics

Group 10—Service Brake System Theory of Operation

Group 15—Mechanical Park Brake Specifications and Adjustments

275

Group 20—Mechanical Park Brake Diagnostics

Group 25—Mechanical Park Brake Theory of Operation

280

**SECTION 270—Hydraulic Operation and Tests**

Group 05—Hydraulic System Diagnostics

Group 10—Hydraulic System Diagnostic Specifications

Group 10A—Hydraulic System Operational Tests and Adjustments

Group 15A—Backshaft Speed Diagnostics

Group 15B—Chaff Spreader Diagnostics

Group 15C—Corn Head Deck Plates Adjust Diagnostics

Group 15D—Cylinder Speed Adjust Diagnostics

Group 15E—Header Raise/Lower Diagnostics

Group 15F—Header Tilt (Contour Master) Diagnostics

Group 15G—Overheating Diagnostics

Group 15H—Overall Diagnostics—Hydraulic System

Group 15I—Reel Belt/Speed Diagnostics

Group 15J—Reel Fore/Aft Diagnostics

Group 15K—Reel Raise/Lower Diagnostics

Group 15L—Unloading Auger Swing Diagnostics

Group 20A—Backshaft Speed Theory of Operation

Group 20B—Chaff Spreader—Theory of Operation

Group 20C—Corn Head Deck Plates Adjust Theory of Operation

Group 20D—Cylinder Speed Adjust Theory of Operation

Group 20E—Header Raise/Lower Theory of Operation

Group 20F—Header Tilt (Contour Master) Theory of Operation

Group 20G—Overheating Theory of Operation

Group 20H—Overall Hydraulic System Theory of Operation

Group 20I—Reel/Belt Speed Theory of Operation

Group 20J—Reel Fore/Aft Theory of Operation

Group 20K—Reel Raise/Lower Theory of Operation

Group 20L—Unloading Auger Swing Theory of Operation

**SECTION 275—Main Engine Gearcase Systems Operation and Test**

Group 00—Engine Gearcase Systems Diagnostics

Group 05—Main Engine Gearcase Hydraulic Specifications

Group 10—Steering System Specifications and Adjustments

Group 15—Steering System Diagnostics

Group 20—Steering System Theory of Operation

Group 25—Separator Drive System Diagnostics

Group 30—Separator Drive System Theory of Operation

Group 35—Separator Drive Pressure Low Diagnostics

Group 40—Separator Drive Temp High Diagnostics

Group 45—Separator Drive Filter Restricted Diagnostics

Group 50—Engine Gearcase Hydraulic Theory of Operation

Group 55—Engine Gearcase Control Valve Theory of Operation

Continued on next page

Group 60—Unloading Auger Engage System  
Diagnostics

Group 65—Unloading Auger Engage System  
Theory of Operation

**SECTION 280—DIAL-A-MATIC System Operation  
and Tests**

Group 00—DIAL-A-MATIC Adjustments

Group 05—DIAL-A-MATIC System Identification

Group 10—DIAL-A-MATIC System—Type A  
Diagnostics

Group 15—DIAL-A-MATIC System—Type B  
Diagnostics

Group 20—DIAL-A-MATIC System Header  
Mechanical Diagnostics

Group 25—DIAL-A-MATIC System—Type A Theory  
of Operation

Group 30—DIAL-A-MATIC System—Type B Theory  
of Operation

**SECTION 290—Heating/Air Conditioning Operation  
and Tests**

Group 05—Specifications and Special Tools

Group 10—Heating/Air Conditioning System  
Diagnostic Information

Group 15—Heating/Air Conditioning System—  
Diagnostics

Group 20—Heating/Air Conditioning—Theory of  
Operation



Thank you very much  
for your reading.  
Please click here  
to get more information.