John Deere 135G (SN. from F500001) Excavator Service Repair Technical Manual (TM14054X19)

F4365 Dry Nutrient Applicator Diagnostic Technical Manual



JOHN HARE



COLLECTION

DIAGNOSTIC TECHNICAL MANUAL F4365 Dry Nutrient Applicator

TM139919 01DEC18 (ENGLISH)



John Deere Des Moines Works

Covers: 135G,1FF135GX_,_F500001�����

Type: Service Manual Language: English Pages: 414 Format: PDF Features: Bookmarked, searchable, printable Compatibility: Windows/Mac/Tablet/Mobile This service manual contains important information for the maintenance, troubleshooting and servicing of the John Deere 135G (SN. from F500001) Excavator Service Repair Technical Manual (TM14054X19)

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.

Contents:

- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...

Please note this manual is in **downloadable PDF format only.** If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

Oil Switch Sending Unit Wiring Lead

Connect wiring lead (1) with nut (2) and tighten.

[39] -




Sensor Wiring Leads

Connect wiring leads (1-5).

[40] - Install engine ground strap.

[41] -



LEGEND:


- 1 Temperature Sending Unit Wiring Lead (BLK)
- 2 Temperature Sending Unit Wiring Lead (RED/WHT)
- 3 QOS Wiring Lead (YEL/BLK)
- 4 Temperature Gauge Wiring Lead (ORG)
- 5 Hot Plug Wiring Lead (YEL)

LEGEND:

- 1 Fuel Shut-Off Solenoid Connector (RED, WHT, BLK)
- 2 Clamp (2 used)
- 3 Fuel Return Line
- 4 Fuel Supply Line

Fuel Return and Supply Line Clamps

Install fuel lines (3 and 4). Connect electrical connector (1). Install clamps (2).



LEGEND: 1 Cap Screw (2 used) 2 Clamp (2 used)

Fuel Line Clamps

Install clamps (2) and cap screws (1).



Thank you very much for your reading. Please click here to get more information.