
## John Deere Timberjack 1158 Diagnostic Wheeled Forwarder Operation and Test (tm1952)



**Covers:** 1158

**Type:** Service Manual **Language:** English

**Pages:** 692 **Format:** PDF

**Features:** Bookmarked, searchable, printable **Compatibility:** Windows/Mac/Tablet/Mobile

This service manual contains important information for the maintenance, troubleshooting and servicing of

the John Deere Timberjack 1158 Diagnostic Wheeled Forwarder Operation and Test (tm1952)

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.


## **Contents:**

- General Information
- Specifications
- · Serial Number Location
- Engine Specifications
- · Engine Diagnostics
- · Engine Tests and Adjustments
- · Engine Repair
- · Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- · Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- · Ignition and Charging
- Steering
- Brakes
- · Wheels
- Operator's Platform
- Body Panels
- · Disassembly and Assembly
- · Diagnostics, Tests and Adjustments
- Troubleshooting
- · and much more...

Please note this manual is in <b>downloadable PDF format only.</b> If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.	

Section 9020 - POWER TRAIN Group 05: Theory of Operation

8	Four M8 Screws with Washers
9	Spring Discs
10	Piston
11	Guide Ring
12	Ring
13	Guide Ring
14	Ring
15	Bleed Screw Cover
16	Parking Brake Bleed Screw
17	Parking Brake Cylinder
13 14 15 16	Guide Ring Ring Bleed Screw Cover Parking Brake Bleed Screw



## Service/Work Brake Cylinder Assembly (Hydraulically Applied and Spring Released)

## LEGEND:

1 Jam Nut

2 Service/Work Brake Adjusting Screw

3 O-ring

4 Bleed Screw Cover



Thank you very much for your reading.

Please click here to get more information.