

450, 455, 750, 1520, 1530,  
1535, 1560, 1590 & 9400  
Grain Drills Diagnostic and  
Repair



JOHN HARE



COLLECTION

**TECHNICAL MANUAL**

**Grain Drills models 450, 455, 750, 1520, 1530, 1535, 1560, 1590, 9400**

TM159219 13 MAY 15 (ENGLISH)



John Deere Agriculture  
Printed by Belgreen



## Table of contents

### **FOREWORD**

#### **Section 10 - SAFETY AND GENERAL INFORMATION**

- Group 05 - Safety
- Group 10 - Lubricants
- Group 15 - General Information
- Group 20 - Repair Specifications

#### **Section 20 - WELDING**

- Group 05 - Repair and Welding

#### **Section 30 - GROUND TOOLS, OPENER DISKS AND PRESS WHEELS**

- Group 05 - Ground Tools—9400 Hoe Drill
- Group 10 - Openers—450, 455, 1520 and 9400 Disk Drill
- Group 11 - Openers—750
- Group 12 - Openers—1530
- Group 13 - Openers—1535
- Group 14 - Openers—1560 and 1590
- Group 20 - Press Wheels—450, 455, 1520 and 9400
- Group 21 - Press Wheel, Gauge Wheel and Closing Wheel—750
- Group 22 - Gauge Wheel and Closing Wheel—1530
- Group 23 - Gauge Wheel and Closing Wheel 1535
- Group 24 - Press Wheel, Gauge Wheel and Closing Wheel—1560 and 1590

#### **Section 40 - ELECTRICAL AND MONITOR SYSTEMS**

- Group 05 - Connector Repair
- Group 10 - Select Lift Control Repair—455
- Group 15 - COMPUTER TRAKCOMPUTER TRAK is a trademark of Deere & Company. Monitor System—455, 750,1560 and 1590
- Group 20 - Steering Control Repair—750 and 1560
- Group 25 - Electronic Population Rate Control

#### **Section 50 - DRIVE SYSTEM**

- Group 05 - Ground Drive Repair
- Group 10 - Meter Drive Repair
- Group 15 - Fertilizer Gear Box Repair
- Group 20 - Grass Seed Drive
- Group 25 - Seed Transmission and Drives 1535

#### **Section 60 - WHEEL BEARINGS AND TIRES**

- Group 05 - Replace Bearings and Inflate Tires

#### **Section 70 - HYDRAULIC SYSTEMS AND COMPONENTS**

- Group 05 - Valve and Motor Repair
- Group 10 - Cylinder Repair

#### **Section 80 - MULTIPLE DRILL HITCHES**

- Group 05 - Identification

#### **Section 90 - ROW MARKERS**

- Group 05 - Repair

#### **Section 100 - SEED BOX REPAIR**

- Group 05 - Repair Seed Box

#### **Section 110 - SEED METERING MECHANISMS**

- Group 05 - Seed Metering Mechanisms

#### **Section 230 - OPENER OPERATION, TESTS AND ADJUSTMENTS**

- Group 05 - Opener Theory of Operation
- Group 10 - Adjust Ground Tools—9400 Hoe Drill
- Group 11 - Adjust Openers—450, 455, 1520 and 9400 Disk Drill
- Group 12 - Adjust Openers—750
- Group 13 - Adjust Openers—1530 and 1535

Group 14 - Adjust Openers—1560 and 1590

Group 15 - Adjust Press Wheels

Group 20 - Troubleshooting

**Section 240 - ELECTRICAL SYSTEM OPERATION**

Group 05 - Wiring Diagrams

Group 10 - Tests and Diagnosis

**Section 250 - DRIVE SYSTEM**

Group 05 - Ground Drive Theory of Operation

Group 10 - Meter Drive Theory of Operation

Group 15 - Grass Seed Drive Theory of Operation

Group 20 - Tests and Adjustments

**Section 270 - HYDRAULIC SYSTEMS OPERATION**

Group 05 - Opener Lift System—450 and 9400

Group 06 - Down-Pressure System—455, 750, 1520, 1560 and 1590

Group 10 - Hitch and Transport Systems

Group 15 - Row Marker System

**Section 280 - MULTIPLE DRILL HITCHES**

Group 05 - 9400 Adjustments

Group 10 - Troubleshooting

**Section 290 - ROW MARKERS**

Group 05 - Adjustments and Troubleshooting

**Section 299 - DEALER FABRICATED TOOL**

Group 05 - Dealer Fabricated Tools





Thank you very much  
for your reading.  
Please click here  
to get more information.