210C, 310C, 315C Backhoe Loader Operation and Test





REFERENCE COPY

Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center. This manual is part of a total product support program.

FOS MANUALS—REFERENCE

TECHNICAL MANUALS-MACHINE SERVICE

COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.

Contents

SECTION I-GENERAL INFORMATION

Group I —Safety Information

Group II —General Specifications

Group III -Torque Values

Group IV —Fuels And Lubricants

SECTION 9005—OPERATIONAL CHECKOUT PROCEDURE

Group 10—Operational Checkout Procedure

SECTION 9010—ENGINE/OPERATION TEST

Group 05—Theory Of Operation

Group 10—System Operational Checks

Group 15—System Diagnostic Information

Group 20—Adjustments

Group 25-Tests

SECTION 9015—ELECTRICAL SYSTEM

Group 00—Electrical System Operation and Test

SECTION 9020—POWER TRAIN

Group 05—Theory Of Operation

Group 10—System Operational Checks

Group 15—System Diagnostic Information

Group 20-Adjustments

Group 25—Tests

SECTION 9025—HYDRAULIC SYSTEM

Group 05-Theory of Operation

Group 10—System Operation Checks

Group 15—System Diagnostic Information

Group 20—Adjustments

Group 25-Tests

SECTION 9030—MISCELLANEOUS SYSTEM (THREE-POINT HITCH)

Group 05—Theory Of Operation

Group 15—Systems Diagnostic Information

Group 25—Tests

Index

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1419-19-28JAN92

COPYRIGHT® 1992
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRUCTION™ Manual
Previous Editions
Copyright® 1988, 1987, 1986, 1985 Deere & Company

9005

9010

9015

_

025

9030

NID.

Contents

900

901

9015

902

9025

903C

(DNI

Section I GENERAL INFORMATION

Contents

Page

Group I —Safety Information

Group II —General Specifications

Group III —Torque Values

Group IV —Fuels And Lubricants



Thank you very much for your reading.

Please click here to get more information.