Compact Utility Tractor 4520, 4720 PIN (650001-) (Without Cab)

TECHNICAL MANUAL

Compact Utility models 4520 PIN (650001-), 4720 PIN (650001-)

TM105119 21 JUL 13 (ENGLISH)

For complete service information also see:

Machine Connection Information	CTM441
POWERTECH 2.4 L & 3.0 L Diesel Engines	CTM301
PowerTech E 2.4L & 3.0L Diesel Engines	CTM101019

John Deere Agriculture
Pinted by Belgreen

TM105119

Table of contents

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.