

468, 468 Silage Special and 568 Round Balers Repair



REPAIR TECHNICAL MANUAL

Round Balers models 468, 568

TM1035 29 DEC 13 (ENGLISH)



John Deere Agriculture
Printed by Belgreen



Table of contents

FOREWORD

Section 10 - GENERAL

- Group 05 - Safety
- Group 10 - Specifications
- Group 15 - General Information
- Group 20 - Lubricants

Section 20 - DRIVE TRAIN

- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Drive Train Protection
- Group 20 - PTO Driveline
- Group 25 - Remove and Install Gear Case
- Group 26 - Gear Case Repair — Iberica
- Group 27 - Gear Case Repair — Comer
- Group 30 - Roll Drives
- Group 35 - Rolls
- Group 40 - Miscellaneous

Section 30 - HYDRAULICS

- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Operation and Tests
- Group 20 - Tensioning Valve Repair
- Group 25 - Gate Lock Valve Repair
- Group 30 - Cylinder Repair

Section 41 - TWINE MECHANISM—ELECTRIC

- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Twine Wrap System Adjustments
- Group 20 - Twine Wrap System Repair

Section 50 - COVEREDGE NET WRAP SYSTEM (IF EQUIPPED)

- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Net Wrap Repair

Section 60 - ELECTRICAL SYSTEM

- Group 05 - General Information
- Group 10 - Common Electrical Tests and Checks
- Group 15 - Diagnosing Malfunctions—BALETRAK Pro System
- Group 20 - Tests and Adjustments—BALETRAK Pro System
- Group 25 - Electrical Diagrams—BALETRAK Pro System
- Group 30 - BALETRAK Pro Monitor-Controller Operations
- Group 35 - Repair—BALETRAK Pro System
- Group 40 - Connector Repair

Section 70 - PICKUP

- Group 05 - General Information
- Group 10 - Diagnosing Malfunctions
- Group 15 - Regular Pickup Repair
- Group 20 - MEGATOOTH Pickup Repair (568 Only)
- Group 25 - MEGAWIDE PLUS Pickup Repair
- Group 30 - Miscellaneous

Section 80 - MISCELLANEOUS

- Group 05 - Wheel Repair
- Group 10 - Gate Repair

Group 15 - Tension Arm Repair

Group 20 - Tongue Repair

Group 25 - Belt Repair

Group 30 - Main Frame Repair

Section 99 - DEALER FABRICATED TOOLS

Group 05 - Dealer Fabricated Tools

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



CAUTION:

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

The technical manual contains two types of information: diagnostics and repair. Diagnostic groups help you identify the majority of routine failures quickly. Repair groups tell how to repair the components.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.



Thank you very much
for your reading.
Please click here
to get more information.