Z915B,Z915E,
Z920M,
Z925M EFI, Z930M,
Z930M EFI, Z950M,
Z920R, Z930R,
Z950R, Z960R,
Z970R ZTrak™
Mowers Diagnostic
and Repair
TECHNICAL MANUAL

TECHNICAL MANUAL

ZTrak B/M/R Series Mower models Z915B, Z915E, Z920M, Z925M EFI, Z930M EFI, Z920R, Z930R, Z950R, Z960R, Z970R, Z950M

TM127619 21APR15 (ENGLISH)



John Deere Commercial and Consumer Equipment Lawn and Garden

TM127619-TECHNICAL MANUAL (g) by Belgreen v2.1

Table of contents

FOREWORD

Section 10 - GENERAL INFORMATION

- Group 05 Safety
- Group 10 General Specifications
- Group 15 Fuel and Lubricant
- Group 40 Machine Specifications

Section 20 - ENGINE REPAIR, KAWASAKI

- Group 05 General Repair FX730V, FX801V, FX850V, and FX1000V
- Group 10 Repair FX730V
- Group 15 Repair FX801V and FX850V
- Group 20 Repair FX1000V

Section 25 - ENGINE REPAIR, KOHLER

- Group 05 Repair CV740 and CV742
- Group 10 Repair ECV740 and ECV749

Section 30 - ELECTRICAL REPAIR

- Group 10 Component Location
- Group 20 Wire Harness, B Series
- Group 25 Wire Harness, M Series
- Group 30 Wire Harness, R Series
- Group 40 Engine Harnesses and Options
- Group 50 General Repair

Section 40 - POWER TRAIN REPAIR

Group 05 - Repair

Section 50 - ATTACHMENTS REPAIR

- Group 10 Component Location
- Group 20 Repair

Section 60 - MISCELLANEOUS REPAIR

- Group 10 Wheels
- Group 20 Operators Station
- Group 30 Roll Over Protective Structure (ROPS)
- Group 40 Miscellaneous

Section 220 - ENGINE DIAGNOSIS, TESTS, AND ADJUSTMENTS, KAWASAKI

- Group 05 Component Location
- Group 10 Theory of Operation
- Group 15 Diagnosis
- Group 20 Tests and Adjustments

Section 225 - ENGINE DIAGNOSIS, TESTS, AND ADJUSTMENTS, KOHLER

- Group 10 Theory of Operation
- Group 20 Diagnosis CV740 and CV742
- Group 25 Diagnosis ECV740 and ECV749
- Group 30 Tests and Adjustments CV740 and CV742
- Group 35 Tests and Adjustments ECV740 and ECV749

Section 230 - ELECTRICAL DIAGNOSIS, TESTS, AND ADJUSTMENTS

- Group 05 Specifications and Information
- Group 10 Theory of Operation
- Group 15 Theory of Operation (EFI)
- Group 20 Diagnosis
- Group 25 Engine Diagnostic Codes (EFI)
- Group 30 Tests and Adjustments
- Group 35 Tests (EFI)
- Group 40 Wiring Schematics
- Group 50 Connectors

TM127619-TECHNICAL MANUAL (g) by Belgreen v2.1

Section 240 - POWER TRAIN DIAGNOSIS, TESTS, AND ADJUSTMENTS

Group 05 - Component Location

Group 10 - Theory of Operation

Group 20 - Diagnosis

Group 30 - Tests and Adjustments

Section 250 - ATTACHMENTS DIAGNOSIS, TESTS, AND ADJUSTMENTS

Group 10 - Theory of Operation

Group 20 - Diagnosis

Group 30 - Tests and Adjustments

Section 299 - SERVICE TOOLS AND KITS

Group 10 - Essential or Recommended Tools

<- Go to Global Table of contents</p>
TM127619-TECHNICAL MANUAL

<- Go to Global Table of contents</p>
TM127619-TECHNICAL MANUAL

GENERAL INFORMATION (g) by Belgreen v2.0

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



CAUTION:

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

<- Go to Section TOC</p>
Section 10 page 1
TM127619-TECHNICAL MANUAL



Thank you very much for your reading.

Please click here to get more information.