# 135C RTS Excavator Repair

# REPAIR TECHNICAL MANUAL RTS models 135C RTS

**TM2094 18AUG15 (ENGLISH)** 

For complete service information also see:

135C RTS Excavator DiagnosticTM2093Super Caddy Oil Cleanup ProcedureCTM310

JDG10274 Ultrasonic Undercarriage

**Measurement Gauge** 

CTM10001



**John Deere Construction and Forestry** 

135C RTS Excavator Repair (g) by Belgreen v2.1

# **Table of contents**

#### **FOREWORD**

# TECHNICAL INFORMATION FEEDBACK FORM

#### Section 00 - GENERAL INFORMATION

Group 0001 - Safety

Group 0003 - Torque Values

# Section 01 - TRACKS

Group 0130 - Track System

# Section 02 - AXLES AND SUSPENSION SYSTEMS

Group 0250 - Axle Shaft, Bearings, and Reduction Gears

Group 0260 - Hydraulic System

# Section 04 - ENGINE

Group 0400 - Removal and Installation

# Section 05 - ENGINE AUXILIARY SYSTEMS

Group 0510 - Cooling System

Group 0515 - Speed Controls

Group 0560 - External Fuel Supply Systems

# Section 17 - FRAME OR SUPPORTING STRUCTURE

Group 1740 - Frame Installation

Group 1749 - Chassis Weights

#### Section 18 - OPERATOR'S STATION

Group 1800 - Removal and Installation

Group 1810 - Operator Enclosure

Group 1821 - Seat and Seat Belt

Group 1830 - Heating and Air Conditioning

# Section 32 - BULLDOZERS (BLADES)

Group 3201 - Blades

Group 3260 - Hydraulic System

#### Section 33 - EXCAVATOR

Group 3302 - Buckets

Group 3340 - Frames

Group 3360 - Hydraulic System

# Section 43 - SWING OR PIVOTING SYSTEM

Group 4350 - Mechanical Drive Elements

Group 4360 - Hydraulic System

#### Section 99 - DEALER FABRICATED TOOLS

Group 9900 - Dealer Fabricated Tools

<- Go to Global Table of contents</p>
135C RTS Excavator Repair

135C RTS Excavator Repair (g) by Belgreen v2.1

# **Foreword**

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



#### **CAUTION:**

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

<- Go to Global Table of contents</p>
135C RTS Excavator Repair



Thank you very much for your reading.

Please click here to get more information.